# PART 3 — AERODROMES (AD)

# **AD 0**

AD 0.1 PREFACE — See AIP Part 1 AD 0.2 RECORD OF AIP AMENDMENTS — See AIP Part 1 AD 0.3 RECORD OF AIP SUPPLEMENTS — See AIP Part 1 AD 0.4 CHECKLIST OF AIP PAGES — See AIP Part 1 AD 0.5 LIST OF HAND AMENDMENTS TO THE AIP — See AIP Part 1

### AD 0.6 TABLE OF CONTENTS TO PART 3

### Page

### AD 1 AERODROME/HELIPORT — INTRODUCTION

AD 1.1	Aerodrome/heliport availabilityAD 1.1 - 1	
	AD 1.1.1 General conditions under which aerodrome/heliport	
	and associated facilities are available for use AD 1.1 - 1	
	AD 1.1.2 Application ICAO documents AD 1.1 - 1	
	AD 1.1.3 Civil use and military air base AD 1.1 - 1	
	AD 1.1.4 CAT II operations at aerodromeAD 1.1 -1	
	AD 1.1.5 Friction Measuring device used and friction level below	
	which the runway is declared slippery when it is wet AD 1.1 - 1	
AD 1.2	Rescue and fire fighting services and snow plan AD 1.2 - 1	
	AD 1.2.1 Rescue and fighting service AD 1.2 - 1	
	AD 1.2.2 Snow plan AD 1.2 - 1	
AD 1.3	Index to aerodromes and heliportsAD 1.3 - 1	
AD 1.4	Grouping of aerodromes / heliports AD 1.4 -	
AD 1.5	Status of certification of aerodromes AD 1.5 - 1	

#### **AD 2 AERODROME**

VMMC AD 2.1	Aerodrome location indicator and name	AD 2 - V	/MMC - 1
VMMC AD 2.2	Aerodrome geographical and administration data	AD 2 - V	<b>MMC - 1</b>
VMMC AD 2.3	Operational hours	AD 2 - V	/MMC - 2
VMMC AD 2.4	Handling services and facilities	AD 2 - V	/MMC - 2
VMMC AD 2.5	Passenger facilities	AD 2 - V	/MMC - 3

VMMC AD 2.6	Rescue and fire fighting services	AD 2 - VMMC - 3
VMMC AD 2.7	Seasonal availability - clearing	AD 2 - VMMC - 3
VMMC AD 2.8	Aprons, taxiways and check location data	AD 2 - VMMC - 4
VMMC AD 2.9	Surface movement guidance and control system	
	and markings	AD 2 - VMMC - 5
VMMC AD 2.10	Aerodrome obstacles	AD 2 - VMMC - 5
VMMC AD 2.11	Meteorological information provided	AD 2 - VMMC - 6
VMMC AD 2.12	Runway physical characteristics	AD 2 - VMMC - 6
VMMC AD 2.13	Declared distances	AD 2 - VMMC - 7
VMMC AD 2.14	Approach and runway lighting	AD 2 - VMMC - 7
VMMC AD 2.15	Other lighting, secondary power supply	AD 2 - VMMC - 7
VMMC AD 2.16	Helicopter landing area	AD 2 - VMMC - 8
VMMC AD 2.17	ATS airspace	AD 2 - VMMC - 8
VMMC AD 2.18	ATS communication facilities	AD 2 - VMMC - 8
VMMC AD 2.19	Radio navigation and landing aids	AD 2 - VMMC - 9
VMMC AD 2.20	Local traffic regulations	AD 2 - VMMC - 10
VMMC AD 2.21	Noise abatement procedures	AD 2 - VMMC - 24
VMMC AD 2.22	Flight procedures	AD 2 - VMMC -26
VMMC AD 2.23	Additional information	AD 2 - VMMC - 26
VMMC AD 2.24	Charts related to an aerodrome	AD 2 - VMMC - 50

# AD 3 HELIPORTS

AD 3.1	Heliport location indicator and name	AD 3 - 1
AD 3.2	Heliport geographical and administration data	AD 3 - 1
AD 3.3	Operational hours	AD 3 - 2
AD 3.4	Handling services and facilities	AD 3 - 2
AD 3.5	Passenger facilities	AD 3 - 3
AD 3.6	Rescue and fire fighting services	AD 3 - 3
AD 3.7	Seasonal availability - clearing	AD 3 - 3
AD 3.8	Aprons, taxiways and check location data	AD 3 - 4
AD 3.9	Markings and markers	AD 3 - 4
AD 3.10	Heliport obstacles	AD 3 - 4
AD 3.11	Meteorological information provided	AD 3 - 5

# AIP MACAO

# AD 0.6 - 3 20 MAR 2014

AD 3.12	Heliport data	AD 3 - 5
AD 3.13	Declared distances	AD 3 - 6
AD 3.14	Approach and FATO lighting	AD 3 - 6
AD 3.15	Other lighting, secondary power supply	AD 3 - 6
AD 3.16	ATS airspace	AD 3 - 7
AD 3.17	ATS communication facilities	AD 3 - 7
AD 3.18	Radio navigation and landing aids	AD 3 - 7
AD 3.19	Flight procedures	AD 3 - 8
AD 3.20	Operational procedures	AD 3 - 10
AD 3.21	Additional information	AD 3 - 11

# **INTENTIONALLY**

# LEFT

# **BLANK**

# AD 1. AERODROME/HELIPORT — INTRODUCTION

#### AD 1.1 AERODROME/HELIPORT AVAILABILITY

- 1. General conditions under which aerodrome/heliport and associated facilities are available for use
- 1.1 Subject to the observance of the applicable rules, conditions, and limitations set forth in this document, foreign civil aircraft registered in a foreign country which at the time is a member of the International Civil Aviation Organisation, may be navigated in Macao.
- 1.2 Aircraft registered under the laws of foreign countries, not members of the International Civil Aviation Organisation, which grant reciprocal treatment to Macao aircraft and airmen may be navigated in Macao subject to the observance of the same rules, conditions, and limitations applicable in the case of aircraft of ICAO member states.
- 1.3 However, excluding when existing bilateral agreements for regular scheduled flights, a prior authorisation has to be forwarded to and granted by the Civil Aviation Authority in conditions laid in GEN 1.2 1 to 1.2 8 of this AIP.
- 1.4 Access of persons to restricted and controlled areas
- 1.4.1 As a general principle, access to restricted areas is only permitted in respect of persons who carry out regular duties in such areas and while performing such duties.
- 1.4.2 Special cases concerning persons whose duties include actually performing activities in restricted areas to an extent as justifies being granted access to such areas, may be considered, but are not included in the item above.
- 1.4.3 The principles governing the access of members of Diplomatic Legations as set forth in the Vienna Convention are upheld, and shall be addressed in the appropriate Resolution.
- 1.4.4 Access to restricted and controlled areas shall be granted by means of permanent or temporary access card, according to circumstances.
- 1.4.5 In order to provide efficient and stringent control of access of persons to restricted areas and controlled areas, the following access cards shall be issued:
  - a) Permanent access card (2 years)
  - b) Temporary access card (up to 5 consecutive days and according to the period authorized)
- 1.4.6 Details of access of persons to restricted and reserved areas refers to FAL/SEC Resolution No. 1/2010.
- 1.5 Access and circulation of vehicles in restricted areas
- 1.5.1 The access and circulation of vehicles in restricted areas is authorised as follow: on a permanent basis in respect of vehicles employed regularly in such areas, or on a temporary or single basis in respect of vehicles occasionally employed in such areas.

- 1.5.2 The authorisation applies only to the vehicle itself. The occupants or load carried in the vehicles, as well as the driver are excluded from such authorisation and shall comply will access rules and other pertaining requirements.
- 1.5.3 The authorisation applies to restricted areas shall further be subject to Safe Circulation Rules (Safety), that shall include, among others, flame damper for exhaust pipes, driver's license, appropriate insurance, etc.
- 1.5.4 The control of access and the surveillance of the circulation of vehicles in restricted areas is done by means of system of identification for vehicles, comprising three modes:
  - a) Fixed identification
  - b) Removable plates

c) Badges

1.5.5 Details of access and circulation of vehicles in restricted areas refers to FAL/SEC Resolution No. 2/95.

### 2. Applicable ICAO documents

ICAO Standards and Recommended Practices contained in Annex 14 are applied in so far as geographical limitations permit. Differences to ANNEX 9 are mentioned in Section GEN 1.7.

### 3. Civil use of military air base

NIL.

# 4. CAT II operations at aerodrome

RWY 34, subject to serviceability of the required facilities, is suitable for CAT II operations by operators whose minima have been accepted by the Civil Aviation Authority. LOW

VISIBILITY OPERATIONS PROCEDURES (LVP) will be in force whenever:

i) Runway Visual Range (RVR) - TDZ RWY 34 - is 800 m or below; or,

ii) Cloud base height (CBH) - RWY 34 - is 200 ft or below; or,

iii) Visibility conditions decrease rapidly;

Pilots will be informed when this procedure is in use by RTF and ATIS through the message "LOW VISIBILITY OPERATIONS IN FORCE".

CAT II operations at MIA by operators of aeroplanes not registered in Macao will be considered under proposal to Civil Aviation Authority indicating the aeroplane type, certification by the State of Registry to operate CAT II and minimum authorised by the State and the operators.

All Weather Operation Manual will be available upon request.

AIP MACAO	AD1.1 - 3
	26 APR 2018

# 5. Friction Measuring device used and friction level below which the runway is declared slippery when it is wet

- 5.1 Runway surface friction at Macao is measured by means of a Mu-meter. Runs are carried out at a speed of 65 km/hour regularly on a dry runway surface using a self-watering device giving a controlled depth of 1 mm of water to monitor the effectiveness of the rubber deposit removal action and surface wear and tear. Should the friction value fall to 0.42 or less the runway will be notified as liable to be slippery when wet and the Macau International Airport Co. Ltd. (CAM), Airport Operations Department should initiate the corrective actions.
- 5.2 If and when such notification is given, there may be a significant deterioration both in aircraft stopping performance and directional control when the runway is wet. Takeoff or landing should then be considered only if the distances available equal to or exceed those required for slippery conditions as determined in the Aeroplane Flight Manual.
- 5.3 If a pilot experiences a significant degradation of the braking action, it should immediately be reported to ATC for relay to subsequent landing aircraft and for follow-up action by CAM, Airport Operations Department.
- 6. Other Information

NIL.

# **INTENTIONALLY**

# LEFT

# **BLANK**

### AD 1.2 RESCUE AND FIRE FIGHTING SERVICES AND SNOW PLAN

#### **1.** Rescue and fire fighting services

Adequate rescue and fire fighting vehicles are provided at Macau International Airport. The degree of protection has been determined in accordance with attachment A to Annex 14. In addition, 5 rescue and fire-fighting vessels with foam and water fire-fighting capability will be available 24 hours a day. AD 2.6 refers.

### 2. Snow Plan

NIL.

# **INTENTIONALLY**

# LEFT

# **BLANK**

	Type of traffic permitted to use the aerodrome/heliport			
	International-		S = Scheduled	Reference to
Aerodrome/heliport	National		NS = Non-scheduled	AD section
Location indicator	(INTL-NTL)	IFR - VFR	P = Private	and remarks
1	2	3	4	5
Aerodromes				
MACAU/International	INTL	IFR - VFR	S - NS - P	AD 2 - VMMC
VMMC				
Heliports				
MACAU/Heliport	INTL	VFR	NS - P	AD 3

# AD 1.3 INDEX TO AERODROMES AND HELIPORTS

# **INTENTIONALLY**

# LEFT

# **BLANK**

# AD 1.4 GROUPING OF AERODROMES/HELIPORTS

NIL.

# **INTENTIONALLY**

# LEFT

# **BLANK**

# AD 1.5 STATUS OF CERTIFICATION OF AERODROMES

Aerodrome Name Location Indicator	Date of Certification	Validity of Certification	Remarks
Macau International Airport VMMC	19 July 2019	5 Years	NIL
Macau Heliport VMMH	30 July 2018	5 Years	NIL

# **INTENTIONALLY**

# LEFT

# **BLANK**

# **AD 2. AERODROME**

# VMMC AD 2.1 AERODROME LOCATION INDICATOR AND NAME

### VMMC - Macau International Airport

### VMMC AD 2.2 AERODROME GEOGRAPHICAL AND ADMINISTRATIVE DATA

1	ARP coordinates and site at AD	22° 08' 58" N 113° 35' 29" E Middle of Runway
2	Direction and distance from city	330° true bearing / 5.4 km to Macao Ferry Terminal
3	Elevation/Reference temperature	6.2 m (20 ft) AMSL / 31.5° C
4	MAG VAR	3°W (2016)
5	AD Administration, address, telephone, telefax, telex, AFS	Airport Director of the Macau InternationalAirport CAM - Macau International AirportCo. Ltd, Airport Operations DepartmentMacau International AirportTaipaMACAUTel : (853) 2886 1111Telefax: (853) 2886 2222AFS : VMMCYDYA
6	Types of traffic permitted (IFR / VFR)	IFR / VFR
7	Remarks	NIL.

1	AD Administration	H24
2	Customs and immigration	H24
3	Health and sanitation	H24
4	AIS Flight Briefing Unit	H24
5	ATS Reporting Office	H24
6	MET Briefing Office	H24
7	ATS	H24
8	Fuelling	H24
9	Handling	H24
10	Security	H24
11	De-icing	NIL.
12	Remarks	NIL.

# VMMC AD 2.3 OPERATIONAL HOURS

# VMMC AD 2.4 HANDLING SERVICES AND FACILITIES

1	Cargo handling facilities	All modern facilities handling weights up to 15 000 kg.
2	Fuel / oil types	Fuel types: AVTUR JET A1 Oil types: As requested by operators maintenance manuals and as engine specifications.
3	Fuelling facilities / capacity	All A "even" parking stands and all B parking stands are hydrant served for AVTUR JET A1
4	De-icing facilities	NIL.
5	Maintenance Hangar space	Limited & unheated, up to B747-400.
6	Repair facilities for visiting aircraft	Line maintenance.
7	Remarks	NIL.

1	Hotels	Unlimited in city hotels.
2	Restaurants	In the city and at airport.
3	Transportation	Taxis and buses.
4	Medical facilities	First aid treatment and hospitals in city.
5	Bank and Post Office	Bank is not available. Only ATM machines and Money exchange counters. Post Office is at AD.
6	Tourist Office	At AD.
7	Remarks	NIL.

# VMMC AD 2.5 PASSENGER FACILITIES

# VMMC AD 2.6 RESCUE AND FIRE FIGHTING SERVICES

1	AD category for fire fighting	Category IX
2	Rescue equipment	Yes Additional: • 5 rescue and fire-fighting (foam with water) vessels • 2 SAR vessel from Marine and Water Bureau (max rescue capacity: 86 persons, and 8 life rafts-50 person each raft)
3	Capability for removal of disabled aircraft	Lifting capability: up to 224 tons
4	Remarks	Fire fighting media and operational reserves in accordance with the equipment laid down in ICAO ANNEX 14.

### VMMC AD 2.7 SEASONAL AVAILABILITY - CLEARING

1	Types of clearing equipment	NIL.
2	Clearance priorities	NIL.
3	Remarks	NIL.

VMMC AD 2.8 APRONS, TAXIWAYS AND CHECK LOCATION	DATA
---	------

1	Apron surface and strength	surface: concrete strength: PCN 65/R/I	3/W/T
2	Taxiway width, surface and Strength	Taxiway C2, C3	width: 23 m surface: concrete strength: PCN 66/R/B/W/T
		Connection ways	
		G	width: 39 m surface: concrete strength: PCN 66/R/B/W/T
		D, E, F	width: 25 m surface: concrete strength: PCN 66/R/B/W/T
		Taxiway Bridge H	width: 23-39 m surface: concrete strength: B747-400 *
		Taxiway Bridge C1	width: 23 m surface: concrete strength: B747-400 *
			l because they are bridges, stance up to 3970 KN d B747-400.
3	ACL location and elevation		ints of RWY 16 and 34 (see : 6.2 m (20 ft) AMSL.
4	VOR/INS checkpoints	VOR: see AD Chart INS: see AD Chart	
5	Remarks	Load limit for a B747	7-400 taking off is 395 900 kg.

### VMMC AD 2.9 SURFACE MOVEMENT GUIDANCE AND CONTROL SYSTEM AND MARKINGS

1	Use of aircraft stand ID signs, TWY guide lines and visual docking / parking guidance system of aircraft stands	Nose-wheel guide line when taxiing on apron and taxiway and enter/exiting the runway. Advanced-Visual Docking Guidance System (AVDGS) is in use for apron parking for stand A04, A02, B02 and B04, and marshalling is provided for the rest of aircraft parking stands.
2	RWY and TWY markings and LGT	RWY: Runway designation, threshold, touchdown zone, centre line, fixed distance marker and side line, marked and lighted TWY: Taxi-holding positions, taxiway intersections, taxiway edge line, ACFT stand line, marked and lighted.
3	Stop bars	Stop bars where appropriate (see chart AD 2 - VMMC – 52)
4	Remarks	NIL.

# VMMC AD 2.10 AERODROME OBSTACLES

	In approach/TKOF are	eas	In circlin	Remarks	
	1			2	3
RWY/Area affected	Obstacles type Elevation Marking/LGT	Coordinates	Obstacle type Elevation Marking/LGT	Coordinates	
a	b	с	a a	b	J
16 / APCH 34 / TKOF	Entrance fairway for Porto Interior & Porto Exterior	NIL.			NII
16 / TKOF 34 / APCH	Entrance fairway for Porto de KA HO	NIL.			NIL.

# VMMC AD 2.11 METEOROLOGICAL INFORMATION PROVIDED

1	Associated MET Office	Macau
2	Hours of service MET office outside hours	H24
3	Office responsible for TAF preparation Periods of validity	Macau MET Office 30 HR
4	Type of landing forecasts Interval of issuance	TREND At least every 30 minutes
5	Briefing/consultation provided	Personal consultation
6	Flight documentation Language used	Charts, METARs, TAFs, SIGMETs, VA and TC advisory information English
7	Charts and other information available for briefing or consultation	Prognostic upper air chart, Significant weather chart, Weather Satellite & Radar, Lighting Detector
8	Supplementary equipment available for providing information	Aviation Weather Information System (AWIS)
9	ATS units provided with information	Macau TWR
10	Additional information (limitations of service etc.)	NIL.

# VMMC AD 2.12 RUNWAY PHYSICAL CHARACTERISTICS

Designations RWY NR	True & MAG BRG	Dimensions of RWY (m)	Strength (PCN) and surface of RWY and SWY	THR coordinates	THR elevation and highest elevation of TDZ of precision APP RWY
1	2	3	4	5	6
16	161° GEO	3360 x 45	PCN 66/R/B/W/T	22° 09' 38.31" N	20 ft
	164° MAG			113° 35' 14.14" E	
34	341° GEO	3360 x 45	PCN 66/R/B/W/T	22° 08' 17.46" N	20 ft
	344° MAG			113° 35' 43.91" E	
Slope of	SWY	CWY	Strip	OFZ	Remarks
RWY-SWY	dimensions (m)	dimensions (m)	dimensions (m)		
7	8	9	10	11	12
0°	60 x 45	60 x 45	3510 x 300	YES	NIL.
0°	60 x 45	60 x 45	3510 x 300	YES	NIL.

# VMMC AD 2.13 DECLARED DISTANCES

RWY Designator	TORA (m)	ASDA (m)	TODA (m)	LDA (m)	Remarks
1	2	3	4	5	6
16	3225	3285	3285	2865	Displaced THR : 360 m
34	3300	3360	3360	2930	Displaced THR : 370 m

# VMMC AD 2.14 APPROACH AND RUNWAY LIGHTING

RWY	APCH	THR	VASIS	TDZ	RWY Centre	RWY edge	RWY End	SWY LGT	Remarks
Designator	LGT type	LGT	(MEHT)	LGT	Line, LGT	LGT, LEN	LEN,	LEN	
	LEN	colour	PAPI	LEN	Length, spacing	spacing colour,	spacing	colour	
	INTST	WBAR			colour, INTST	INTST	colour		
							WBAR		
1	2	3	4	5	6	7	8	9	10
16	SIAL	GREEN	PAPI	NIL	2865 m, 30 m*,	3460 m, 60 m	Red	60 m	* ICAO
	600 m	-	Both / 3°		LIH	White - 2280 m	-	Red	standard
	LIH		(70.87 ft/			Yellow - 600 m			colour
			21.60 m)			LIH			coding
34	CAT 1-2-	GREEN	PAPI	900 m	2930 m, 30 m*,	3460 m, 60 m	Red	60 m	
	3	-	Right / 3°		LIH	White - 2340 m	-	Red	
	420 m		(65 ft/			Yellow - 600 m			
	LIH		19.81 m)			LIH			

# VMMC AD 2.15 OTHER LIGHTING, SECONDARY POWER SUPPLY

1	ABN/IBN location, characteristics and hours of operation	NIL.
2	LDI location and LGT Anemometer location and LGT	LDI: NIL. Surface wind: One at touchdown zone of RWY 16 One at touchdown zone of RWY 34 One at middle All are 130 m East of RWY centre line Cloud base: Two (105 m East of RWY centre line), one at each RWY end
3	TWY edge and centre line lighting	Edge : TWY D, E, F, C3 Section of TWY H, G, & C1 – red obstacle lights at taxiway edge Centre line : All TWY
4	Secondary power supply / switch- over time	one generator on each sub-station (3 in total) up to 500 KVA. CAT II ILS operations relying on main generator, and with back-up on commercial power. Switch-over time: 0.5 sec
5	Remarks	NIL.

# VMMC AD 2.16 HELICOPTER LANDING AREA NIL.

# VMMC AD 2.17 ATS AIRSPACE

1	Designation and lateral limits	Macau Aerodrome Traffic Zone (ATZ).
		The Macau ATZ is a regulated airspace, extending in a circle of 5 NM radius from the aerodrome reference point except to the west where the boundary is a straight line parallel to the runway at a distance of 3 NM. There is a 5NM wide stub, out to 10NM on the approach to runway 34 and a 2 NM wide stub out to 6.27 NM (Jiuzhou DVOR) on the 215° (true bearing) inbound track to the runway 16 LOC.
2	Vertical limits	SFC to 3000 ft (900 m) AMSL
3	Airspace classification	С
4	ATS unit call sign Language(s)	Macau Tower English
5	Transition altitude	Refer to ENR 1.7
6	Remarks	NIL.

# VMMC AD 2.18 ATS COMMUNICATION FACILITIES

Service	Call sign	Frequency	Hours of	Remarks
designation	C C		operation	
1	2	3	4	5
TWR	MACAU TWR	118.000 MHz	H24	Primary control channel
		119.400 MHz		Secondary control channel
Ground control	MACAU Ground	121.725 MHz	H24	Primary control channel
		121.975 MHz		Secondary control channel
Emergency	Emergency	121.500 MHz	H24	Emergency
ATIS	MACAU ATIS	126.400 MHz	H24	Broadcast only
*Liaison of fire		*123.100 MHz	H24	Auxiliary frequency SAR
fighting service				*to be used on ground, for
to aircraft crew				actual fire crash fighting
				only
Search and		125.150 MHz	H24	For communication with
Rescue (Main)				SAR vessels and SAR
				aircraft
Search and		120.800 MHz	H24	Back up of 125.150 MHz
Rescue (Back up)				
		122.350 MHz	H24	Reserved

# VMMC AD 2.19 RADIO NAVIGATION AND LANDING AIDS

Type of aids, CAT of ILS / MLS(For VOR / ILS / MLS, give VAR)	ID	Frequency	Hours of operation	Site of transmitting antenna coordinates	Elevation of DME transmitting antenna	Remarks
1	2	3	4	5	6	7
LOC 34 ILS CAT II CLASS II/T/4 (3° W / 2016)		109.700 MHz	H24	22°09'54''N 113°35'09'E		ICAO Facilities
DME	MCN	CH. 34X	H24	22°08'28"N 113°35'44"E	3.8 m / 12.5 ft	Performance CAT II
GP 34 CLASS II/T/4		333.200 MHz	H24	22°08'28"N 113°35'44"E		
LOC 16	MCS	111.700 MHz	H24	22°09'40''N	87 m / 285.5 ft	
DME	MCS	CH. 54X	H24	113°32'54"E	87 III / 283.3 It	
DVOR	MCU	116.400 MHz	H24	22°08'08''N 113°35'52''E	9.1 m / 30 ft	unusable within sector 230° to 260° clockwise at and below 2700 ft
DME		CH. 111X				
DVOR	ZAO	117.200 MHz	H24	22°14'42''N	47.3 m	
DME	ZAU	СН. 119Х	Π24	113°36'42"E	47.3 111	
Secondary radar		1030 MHz / 1090 MHz	H24	22°07'14"N 113°33'43"E		Monitoring purpose only

# VMMC AD 2.20 LOCAL TRAFFIC REGULATIONS

- 1 Aircraft flying to and from the airport are not allowed to overfly urban, populated areas on the North and West shore of Macau International Airport, comprising Macau Peninsula, and Taipa and Coloane Islands
- 2 Turbulence may be encountered.
- 3 Pilots are warned that VFR holding by fixed-wing and rotary-wing light aircraft, one at a time, may take place from time to time during daylight and night hours east of the runway.
- 4 **Overflight of urban area.**

All aircraft are forbidden to fly over the urban area in Macao Special Administrative Region.

### 5 Transit and departure conditions for engine - out ferry flights

### 5.1 General conditions

- 5.1.1 Transit engine-out ferry operations through Macao will not be permitted.
- 5.1.2 Departure engine-out ferry operations will only be permitted if so approved in the airplane Flight Manual.
- 5.1.3 No form of revenue load is to be carried.
- 5.1.4 Aerodrome operating minima are to be not less than 1000 ft cloud ceiling and 5 km (2.7 NM) visibility.
- 5.1.5 In the ATC flight plan, an engine-out ferry flight is to be notified and confirmation that the conditions for engine-out ferry flight will completed with must be included in item 18 by the insertion of a statement:

# 5.2 Conditions for departing flights

- 5.2.1 Engine-out ferry flights departing from Macao must obtain prior permission from the Civil Aviation Authority.
- 5.2.2 Engine-out ferry take-off must be operated on Runway 16.
- 5.2.3 The aircraft must be operated at a weight which, in the event of future engine failure at or after V1, will enable a positive net flight path to be maintained and standard ICAO obstacle clearance requirements to be met.

# 6. Ground manoeuvring of aircraft at Macau International Airport

- 6.1 Legislation
- 6.1.1 The rules concerning ground manoeuvring of aircraft and vehicles are indirectly specified in Eleventh Schedule to the Air Navigation Regulation of Macao.

# 6.2 Definition of taxiing aircraft

- 6.2.1 Aircraft taxiing are those aircraft manoeuvring under the following conditions:
  - (1) Aircraft moving under their own power within the airport boundaries or any part of the airport subject to communal use, excluding take-off and landing.
  - (2) Aircraft being moved with the assistance of auxiliary power i.e. tractor, jeep or by any other mechanical means.
  - (3) Aircraft being manoeuvred by hand.

Note: Aircraft classified under 1), 2) and 3) above are not subject to these regulations unless they are moved along or across runway or taxiways, in which case they are considered to be taxiing.

### 6.3 Local taxiing / air-taxiing regulations

- 6.3.1 Overtaking of moving aircraft at Macau International Airport when taxiing is prohibited.
- 6.3.2 When taxiing/air-taxiing on the Terminal apron aircraft shall follow the nose-wheel guide lines at all times. Marshalling service will normally be available to assist pilots in the correct positioning of their aircraft whilst parking.

Note: Pilots should exercise extreme caution when manoeuvring on the aprons due to the proximity of other aircraft, ground staff and equipment. Engine power should be restricted to the minimum required to reduce the adverse effect of jet blast. A case in point is the use of greater than normal breakaway thrust when making the turn from the parking bay to the taxiway centreline. Pilots should restrict the power setting to the absolute minimum necessary to execute the turn.

#### 6.4 Aircraft equipped with radio

- 6.4.1 Before the commencement of any manoeuvre, all aircraft equipped with radio, except those specified in the "Note" to paragraph 6.2 above are to call "Ground" on 121.725 MHz or Macau Tower on 118.0 MHz when Ground control is not in operation.
- 6.4.2 A person qualified, as in paragraph 6.6 below, shall be in charge of all movements. If voice communication cannot be established, the aircraft is to remain in position and comply with regulations applicable to aircraft not fitted with radio.

### 6.5 Aircraft unable to establish radio contact

6.5.1 When aircraft that are unable to establish radio contact are to be moved, details of all such manoeuvres are to be passed by telephone or personal contact the Airport Operation Centre.

#### 6.6 Persons qualified to taxi / air-taxi aircraft

- 6.6.1 No person may taxi/air-taxi an aircraft on Macau International Airport unless he is qualified under one of the following categories:
- 6.6.1.1 A licensed pilot in possession of a valid license to operate that type of aircraft ;
- 6.6.1.2 A Student Pilot under instruction who has been authorised by a Flying Instructor in possession of a valid instructor's license for that type of aircraft.

### 6.7 Towing aircraft

All towing manoeuvring not intended for departure shall be previously coordinated with airport operations service.

### 7 Regulations for local flights in the Macau Aerodrome Traffic Zone (ATZ)

# 7.1 ATC Unit

Flights within the ATZ are under the control of Aerodrome Control, call sign "Macau Tower", operating on 118.0 MHz for air movements and "Macau Ground" operating on 121.725 MHz for ground movements.

- 7.2 General rules
- 7.2.1 ATC clearance for local flying will only be given if, in the assessment of the Aerodrome Control, such flying will not interrupt or unnecessarily delay the normal operation of public transport aircraft.
- 7.2.2 Solo flights by non-licensed pilots are prohibited.
- 7.2.3 Before entering the ATZ, pilots shall request ATC clearance.
- 7.2.4 Before leaving the ATZ, pilots shall inform ATC of their exit point and destination before changing to the next ATC unit.
- 7.2.5 VFR flights during daylight hours may be cleared by ATC provided the weather observation at Macau International Airport shows a visibility of at least 5 km and a cloud ceiling of not less than 1500 ft.

### 7.3 Fixed-wing aircraft operations

7.3.1 Take-off and Landing restrictions

See charts

7.3.2 Traffic Circuit

See charts

- 7.3.3 Weather Minima
- 7.3.3.1 Circuit operations are not permitted when the visibility is less than 5 km or the lowest cloud is lower than 1500 ft in the circuit area.
- 7.3.3.2 Low visibility operation minimum: see AD chart.
- 7.3.4 Night flying
- 7.3.4.1 Special VFR flights at night may be cleared by Macau Tower providing that:
  - (1) Traffic density is such that flights will not delay public transport aircraft.
  - (2) Weather observations show a visibility of at least 9 km and a cloud ceiling of not less than 1800 ft.

- (3) The scale of equipment carried by the aircraft is adequate for flying at night.
- (4) The flight is contained in Macau ATZ, or

(5) The flight has been initiated and authorised by adjacent ATS Unit, or has been accepted by an adjacent ATZ unit.

#### 8 Push - back and start - up procedures

- 8.1 All aircraft other than helicopters are to call one of the following services five minutes prior to start-up to put their clearance on request:
- 8.1.1 Macau Ground 121.725 MHz permanent
- 8.1.2 Macau Tower 118.000 MHz permanent
- 8.2 Pilots are to inform Macau Ground/Tower as appropriate their callsign, parking bay number/location and proposed flight level if it is different from the filed flight plan when they make the call as per para. 8.1 above.
- 8.3 Aircraft should not commence start-up, push back or any other manoeuvre on the apron unless they have obtained clearance from Macau Ground/Tower as appropriate.
- 8.4 Aircraft start-up engines will be allowed by Macau Control Tower, after the engines clear the white taxi line protection.
- 8.5 Whilst push back procedure is being conducted it is essential for safety reasons that communications contact is maintained between pilot and ground engineer in charge.
- 8.6 Once a request for clearance has been made as per para. 8.1 above, delays in getting ready to start, taxi or take-off may result in withdrawal of ATC clearance.

#### 8.7 Color-Coded Aircraft Pushback Procedures

	RWY 34/16 Departure		
	Normal pushback &	Pushback after engine	
STAND NUMBER	start-up	started-up	
A1-A15,A17, B1-B6, B8	BLUE	BLUE	
<b>B7, B10, B10L, B10R</b>	GREEN	<b>GREEN/PINK</b>	
G01-G15	FOLLOW BREAKAWAY	N/A	
	<b>POINT "X", "Y" OR "Z"</b>		

	Color-coded Push back Procedures			
	Color Code	Detailed Description		
	BLUE	Aircraft pushback facing South or North depending on the Runway-in-use. If necessary, special instruction will be issued by Control Tower. Startup can be commenced after the engines cross the white taxi line protection.		
	GREEN	<ul> <li>Pushback of aircraft with wingspan less than 36m on B7, B10, B10L, B10R shall be done by pushing the aircraft tail towards GAP and then towed forward until Breakaway Point 1 in normal situation or in situation that aircraft with APU problem and requires starting up engine on stand while No aircraft is parked on G05 to G08.</li> <li>Pushback of aircraft with wingspan equal to or greater than 36m on B7, B10 shall be done by pushing the aircraft tail towards GAP and then towed forward until Breakaway Point 2 in normal situation or in situation that aircraft with APU problem and requires starting up engine on stand while No aircraft tail towards GAP and then towed forward until Breakaway Point 2 in normal situation or in situation that aircraft with APU problem and requires starting up engine on stand while No aircraft is parked on G05 to G08.</li> <li>Except that the startup on stand due to APU problem, other startup can only be</li> </ul>		
	PINK	commenced when the pushback finishes at Breakaway Point.The pink procedure requires pushing the aircraft tail towards North until either the beginning of Taxiway C1 for RWY16 departure or taxiway A for RWY34 departure. Except that the startup on stand due to APU problem, other startup can only be commenced when the pushback finishes. The procedure applies for Pushback of aircraft with APU problem, which requires to start up engine on stand B7 or B10, B10L or B10R while aircraft is parked on G05 to G08.		
<b>Rei</b> 1. 2.	For aircraft sta (for follow-me safety.	rked on Stands B1 and B3, no simultaneous pushback is allowed. art up on the Stand, coordination shall be done in advance among ATC, Pilot and AOCC e to inspect the surrounding area of the aircraft involved) in order to guarantee ground		

3. The Breakaway point 1 mentioned above is the one at B7 and Breakaway point 2 is one between B5 and B7.

 For blue procedure, the color code may be omitted in the air-ground communication between ATC and pilot.


l

G01 – G15 Push Back /Tow Procedures			
Aircraft Stand	Nose wheel on Breakaway Point	Detailed Description	
G01, G02, G03, G04	V	Aircraft shall be <u>pushed back</u> following the BLUE lead out line until the aircraft tail towards Cargo Roadway, and then pull ahead up to Breakaway Point "X".	
G05, G06	X	Aircraft shall be <u>towed out</u> following the BLUE lead out line until the aircraft tail towards Cargo Roadway, and then pull ahead up to the Breakaway Point "X".	
G07, G08, G09, G10	Y	Aircraft shall be <u>towed out</u> following the BLUE lead out line and until the aircraft tail towards Cargo Roadway, and then pull ahead up to the Breakaway Point "Y".	
G11, G12		Aircraft shall be <u>towed out</u> following the BLUE lead out line and taxilane centre line up to the Breakaway Point "Z".	
G13, G14, G15	Z	Aircraft shall be <u>pushed back</u> following the BLUE lead out line until the aircraft tail towards East Roadway, and then pull ahead up to the Breakaway Point "Z".	

Remarks:


- 1) All GA/helicopter arrivals will be guided by Follow-me to the designated aircraft stands.
- 2) The Breakaway Points "X", "Y" and "Z" are located on the taxilane centre line behind G03, ahead of G10, and behind G13 respectively.
- 3) Helicopter operations are exempted from following the defined Breakaway Points but are required to be pushed /towed to the taxilane abeam its parking stand for startup and taxi out.
- 4) Two wing walkers are mandatory to be present for all pushback/tow manoeuvres.
- 5) NO simultaneous pushback / tow operations on Breakaway Points "Y" and "Z" is allowed.
- 6) NO engine start up on stand before pushback / tow is allowed. Exception can be considered for aircraft parked on G06, G08, G10 or G13 with coordination made in advance among AOCC, Ground Handling Agent (GHA), Pilot and ATC. Follow-me shall inspect the surrounding area of the aircraft involved and ensure the following conditions are met prior to aircraft start up and taxi out at its own power.

Aircraft Stand	Direct-taxi-out Conditions
G06	G05 & G08 are clear
G08	G06 & G07 are clear
G10	G09 & G12 are clear
G13	B07 & adjacent Equipment Parking Areas are clear




# AIRCRAFT PUSHBACK BLUE PROCEDURE (RWY 34)


AIRCRAFT PUSHBACK BLUE PROCEDURE (RWY 16)



#### AIRCRAFT PUSHBACK GREEN PROCEDURE FOR B7 AND B10 (WINGSPAN≥36M) NORMAL AND STARTED-UP WITHOUT AIRCRAFT ON G05 to G08





# AIRCRAFT PUSHBACK PINK PROCEDURE FOR B7 AND B10, B10L, B10R (RWY 16)



#### AIRCRAFT PUSHBACK / TOW PROCEDURE FOR BREAKAWAY POINT "X" (RWY 34 / 16)


**Stands G01 – G06** 





#### AIRCRAFT PUSHBACK / TOW PROCEDURE FOR BREAKAWAY POINT "Y" (RWY 34 / 16) Stands G07 – G10

AIRCRAFT PUSHBACK / TOW PROCEDURE FOR BREAKAWAY POINT "Z" (RWY 34 / 16)



Civil Aviation Authority – Macao, China

#### 9 Advanced-Visual Docking Guidance System (AVDGS)

9.1 The Advanced-Visual Docking Guidance System (AVDGS) provides both pilots with guidance for manoeuvring the aircraft into the gate to the correct centerline and stopposition Aircraft parking visual docking guidance system.

AVDGS is installed on stands A06, A04, A02, B02, B04, B06, B08 and B10/10L/10R.

The Airport Authority will provide marshalling service for other aircraft not included on AVDGS .

In all other stands, the aircraft parking manoeuvre will be signaling by a marshaller.

9.2 AVDGS Procedure

1	START-OF-DOCKING The system is started by pressing one of the aircraft type buttons on the Operator Panel. When the button has been pressed, WAIT will be displayed.	WAIT
2	CAPTURE The floating arrows indicate that the system is activated and in	ASOU
	capture mode, searching for an approaching aircraft.	
	It shall be checked that the correct aircraft type is displayed. The lead-in line shall be followed.	
	THE PILOT MUST NOT PROCEED BEYOND THE BRIDGE, UNLESS THE ARROWS HAVE BEEN SUPERSEDED BY THE CLOSING RATE BAR.	
3	TRACKING	
	When the aircraft has been caught by the laser, the floating arrow is replaced by the yellow center line indicator.	, Hacu
	A flashing red arrow indicates the direction to turn.	
	The vertical yellow arrow shows position in relation to the center line. This indicator gives correct position and azimuth guidance.	
4	CLOSING RATE	esen
	The closing rate is the final countdown from a specific distance to the stop position. A yellow vertical closing rate bar/center line indicator appears with or without a digital countdown, depending on the configuration.	>16.0m
	The closing rate bar represents the distance from stop, it consists of a number of rows representing 0.5m per row. Each row turns	

off as the aircraft approaches stop (reducing the length of the bar, bottom upwards) and as the last row turns off, less than the interval for one row remains until STOP appears.       Meters (m)         A digital countdown shows the distance to stop numerically, starting from 30 m.       The digital countdown also uses different decrements during the closing rate process.       Metric digital count starting with 1 meter decrements from 30 m down to 2 m followed by 0.2 meter decrements from 2.0 down to 0.2 m and then followed by STOP.         The pictures illustrate aircraft in the closing rate distance from stop position, slightly left of the center line. The red arrow indicates the direction to steer.         5       ALIGNED TO CENTRE         The aircraft is at the displayed distance from the stop position. The absence of any direction arrow indicates an aircraft on the center line.         6       SLOW (DECREASE SPEED)         AVDGS is configured with a slowdown active zone (distances set from the stop position, between 6 to 24 meters) according to an acceptable docking speed (max allowed speed, 2 m/s).         Note: When 2 m/s is rounded down to a single digit, it is approximately 7 km/h, 4 mph or 3 knots.         If the aircraft is approaching faster than the accepted speed, the system will show 'SLOW' or 'SLOW DOWN' as a warning to the pilots.         7       AZIMUTH GUIDANCE         The aircraft is at the displayed distance from the stop-position. The yellow arrow indicates an aircraft to the right of the center line, and the red flashing arrow indicates the direction to turn.			18 AFK 2013
starting from 30 m.         The digital countdown also uses different decrements during the closing rate process.         • Metric digital count starting with 1 meter decrements from 30 m down to 2 m followed by 0.2 meter decrements from 2.0 down to 0.2 m and then followed by STOP.         The pictures illustrate aircraft in the closing rate distance from stop position, slightly left of the center line. The red arrow indicates the direction to steer.         5       ALIGNED TO CENTRE         The aircraft is at the displayed distance from the stop position. The absence of any direction arrow indicates an aircraft on the center line.         6       SLOW (DECREASE SPEED)         AVDGS is configured with a slowdown active zone (distances set from the stop position, between 6 to 24 meters) according to an acceptable docking speed (max allowed speed, 2 m/s).         Note: When 2 m/s is rounded down to a single digit, it is approximately 7 km/h, 4 mph or 3 knots.         If the aircraft is approaching faster than the accepted speed, the system will show 'SLOW' or 'SLOW DOWN' as a warning to the pilots.         7       AZIMUTH GUIDANCE         The aircraft is at the displayed distance from the stop-position. The yellow arrow indicates an aircraft to the right of the center ine, and the red flashing arrow indicates the direction to turn.		bottom upwards) and as the last row turns off, less than the	Meters (m)
closing rate process.       • Metric digital count starting with 1 meter decrements from 30 m down to 2 m followed by 0.2 meter decrements from 2.0 down to 0.2 m and then followed by STOP.         The pictures illustrate aircraft in the closing rate distance from stop position, slightly left of the center line. The red arrow indicates the direction to steer.         5       ALIGNED TO CENTRE         The absence of any direction arrow indicates an aircraft on the center line.          6       SLOW (DECREASE SPEED)         AVDGS is configured with a slowdown active zone (distances set from the stop position, between 6 to 24 meters) according to an acceptable docking speed (max allowed speed, 2 m/s).          Note: When 2 m/s is rounded down to a single digit, it is approximately 7 km/h, 4 mph or 3 knots.         If the aircraft is approaching faster than the accepted speed, the system will show 'SLOW' or 'SLOW DOWN' as a warning to the pilots.          7       AZIMUTH GUIDANCE         The aircraft is at the displayed distance from the stop-position.         The aircraft is at the displayed distance from the stop-position.         The aircraft is at the displayed distance from the stop-position.         The aircraft is at the displayed distance from the stop-position.         The aircraft is at the displayed distance from the stop-position.         The aircraft is at the displayed distance from the stop-position.         The aircraft is at the displayed distance from the stop-position.         The aircraft is at the displayed distance from the stop-position.         The yellow arrow indicates the direction to turn.			
m down to 2 m followed by 0.2 meter decrements from 2.0 down to 0.2 m and then followed by STOP.       The pictures illustrate aircraft in the closing rate distance from stop position, slightly left of the center line. The red arrow indicates the direction to steer.         5       ALIGNED TO CENTRE The aircraft is at the displayed distance from the stop position. The absence of any direction arrow indicates an aircraft on the center line.       Image: Comparison of the center line.         6       SLOW (DECREASE SPEED)       Meters (m)         6       SLOW (DECREASE SPEED)         AVDGS is configured with a slowdown active zone (distances set from the stop position, between 6 to 24 meters) according to an acceptable docking speed (max allowed speed, 2 m/s). Note: When 2 m/s is rounded down to a single digit, it is approximately 7 km/h, 4 mph or 3 knots. If the aircraft is approaching faster than the accepted speed, the system will show 'SLOW' or 'SLOW DOWN' as a warning to the pilots.       Meters (m)         7       AZIMUTH GUIDANCE The aircraft is at the displayed distance from the stop-position. The yellow arrow indicates an aircraft to the right of the center line, and the red flashing arrow indicates the direction to turn.       Image: Comparison of the center line, and the red flashing arrow indicates the direction to turn.			
<ul> <li>stop position, slightly left of the center line. The red arrow indicates the direction to steer.</li> <li>ALIGNED TO CENTRE The aircraft is at the displayed distance from the stop position. The absence of any direction arrow indicates an aircraft on the center line.</li> <li>SLOW (DECREASE SPEED) AVDGS is configured with a slowdown active zone (distances set from the stop position, between 6 to 24 meters) according to an acceptable docking speed (max allowed speed, 2 m/s). Note: When 2 m/s is rounded down to a single digit, it is approximately 7 km/h, 4 mph or 3 knots. If the aircraft is approaching faster than the accepted speed, the system will show 'SLOW' or 'SLOW DOWN' as a warning to the pilots.</li> <li>AZIMUTH GUIDANCE The aircraft is at the displayed distance from the stop-position. The yellow arrow indicates an aircraft to the right of the center line, and the red flashing arrow indicates the direction to turn.</li> </ul>		m down to 2 m followed by 0.2 meter decrements from 2.0 down	
The aircraft is at the displayed distance from the stop position. The absence of any direction arrow indicates an aircraft on the center line.Image: Constraint of the stop position. Meters (m)6SLOW (DECREASE SPEED) AVDGS is configured with a slowdown active zone (distances set from the stop position, between 6 to 24 meters) according to an acceptable docking speed (max allowed speed, 2 m/s). Note: When 2 m/s is rounded down to a single digit, it is approximately 7 km/h, 4 mph or 3 knots. If the aircraft is approaching faster than the accepted speed, the system will show 'SLOW' or 'SLOW DOWN' as a warning to the pilots.Image: Constraint of the stop-position. The aircraft is at the displayed distance from the stop-position. The yellow arrow indicates an aircraft to the right of the center line, and the red flashing arrow indicates the direction to turn.Image: Constraint of the stop-position to turn.		stop position, slightly left of the center line. The red arrow	
<ul> <li>The absence of any direction arrow indicates an aircraft on the center line.</li> <li>The absence of any direction arrow indicates an aircraft on the center line.</li> <li>Meters (m)</li> <li>SLOW (DECREASE SPEED)         AVDGS is configured with a slowdown active zone (distances set from the stop position, between 6 to 24 meters) according to an acceptable docking speed (max allowed speed, 2 m/s).         Note: When 2 m/s is rounded down to a single digit, it is approximately 7 km/h, 4 mph or 3 knots.         If the aircraft is approaching faster than the accepted speed, the system will show 'SLOW' or 'SLOW DOWN' as a warning to the pilots.         AZIMUTH GUIDANCE         The aircraft is at the displayed distance from the stop-position. The yellow arrow indicates an aircraft to the right of the center line, and the red flashing arrow indicates the direction to turn.         <b>Figure 1 Figure 2 Figure 3 Figur</b></li></ul>	5	ALIGNED TO CENTRE	nsen (
<ul> <li>6 SLOW (DECREASE SPEED)</li> <li>AVDGS is configured with a slowdown active zone (distances set from the stop position, between 6 to 24 meters) according to an acceptable docking speed (max allowed speed, 2 m/s). Note: When 2 m/s is rounded down to a single digit, it is approximately 7 km/h, 4 mph or 3 knots. If the aircraft is approaching faster than the accepted speed, the system will show 'SLOW' or 'SLOW DOWN' as a warning to the pilots.</li> <li>7 AZIMUTH GUIDANCE The aircraft is at the displayed distance from the stop-position. The yellow arrow indicates an aircraft to the right of the center line, and the red flashing arrow indicates the direction to turn.</li> </ul>		The absence of any direction arrow indicates an aircraft on the	
<ul> <li>AVDGS is configured with a slowdown active zone (distances set from the stop position, between 6 to 24 meters) according to an acceptable docking speed (max allowed speed, 2 m/s). Note: When 2 m/s is rounded down to a single digit, it is approximately 7 km/h, 4 mph or 3 knots. If the aircraft is approaching faster than the accepted speed, the system will show 'SLOW' or 'SLOW DOWN' as a warning to the pilots.</li> <li>7 AZIMUTH GUIDANCE The aircraft is at the displayed distance from the stop-position. The yellow arrow indicates an aircraft to the right of the center line, and the red flashing arrow indicates the direction to turn.</li> </ul>			Meters (m)
<ul> <li>set from the stop position, between 6 to 24 meters) according to an acceptable docking speed (max allowed speed, 2 m/s).</li> <li>Note: When 2 m/s is rounded down to a single digit, it is approximately 7 km/h, 4 mph or 3 knots.</li> <li>If the aircraft is approaching faster than the accepted speed, the system will show 'SLOW' or 'SLOW DOWN' as a warning to the pilots.</li> <li>7 AZIMUTH GUIDANCE         The aircraft is at the displayed distance from the stop-position. The yellow arrow indicates an aircraft to the right of the center line, and the red flashing arrow indicates the direction to turn.     </li> </ul>	6	SLOW (DECREASE SPEED)	
<ul> <li>approximately 7 km/h, 4 mph or 3 knots.</li> <li>If the aircraft is approaching faster than the accepted speed, the system will show 'SLOW' or 'SLOW DOWN' as a warning to the pilots.</li> <li>7 AZIMUTH GUIDANCE</li> <li>The aircraft is at the displayed distance from the stop-position. The yellow arrow indicates an aircraft to the right of the center line, and the red flashing arrow indicates the direction to turn.</li> </ul>		set from the stop position, between 6 to 24 meters) according to	7.00
<ul> <li>system will show 'SLOW' or 'SLOW DOWN' as a warning to the pilots.</li> <li>7 AZIMUTH GUIDANCE         The aircraft is at the displayed distance from the stop-position. The yellow arrow indicates an aircraft to the right of the center line, and the red flashing arrow indicates the direction to turn.     </li> </ul>			
The aircraft is at the displayed distance from the stop-position. The yellow arrow indicates an aircraft to the right of the center line, and the red flashing arrow indicates the direction to turn.		system will show 'SLOW' or 'SLOW DOWN' as a warning to	Meters (m)
The yellow arrow indicates an aircraft to the right of the center line, and the red flashing arrow indicates the direction to turn.	7	AZIMUTH GUIDANCE	Agen
Meters (m)		The aircraft is at the displayed distance from the stop-position.	4.0m
		The yellow arrow indicates an aircraft to the right of the center	

8	STOP POSITION REACHED When the correct stop-position is reached, the display will show STOP with a red border or with red lights.	STOP
9	DOCKING COMPLETED When the aircraft has parked, OK will be displayed.	OK
10	CHOCK ON CHOCK ON will be displayed, when the ground staff has put the chocks in front of the nose wheel and press the "Chocks On" button on the Operator Panel	CHOCK
11	STOP SHORT If the aircraft is found standing still but has not reached the intended stop position, the message STOP OK will be shown after a pre-configured time.	(STOP) OK
12	WAIT If some object is blocking the view toward the approaching aircraft or the detected aircraft is lost during docking close to STOP, the display will show WAIT. The docking will continue as soon as the blocking object has disappeared or the system detects the aircraft again. THE PILOT MUST NOT PROCEED BEYOND THE BRIDGE, UNLESS THE "WAIT" MESSAGE HAS BEEN SUPERSEDED BY THE CLOSING RATE BAR.	

13	SLOW (IN ABNORMAL SITUATIONS)	ason
	This display can be shown for two reasons:	SLOW
	A) BAD WEATHER CONDITION	
	During heavy fog, rain or snow, the visibility for the docking system can be reduced. When the system is activated and in capture mode, the display will disable the floating arrows and display SLOW and the Aircraft Type.	
	As soon as the system detects the approaching aircraft, the vertical closing rate bar will appear. If the system has been configured in this mode to make a shortened ID verification (check of engine position excluded), the Aircraft symbol will blink to give attention.	
	B) AIRCRAFT LOST DURING DOCKING	
	If the aircraft is lost during docking far out from the bridge or PBB area, the display will show SLOW. As soon as the system detects the approaching aircraft, the vertical closing rate bar will re –appear.	
	THE PILOT MUST NOT PROCEED BEYOND THE BRIDGE, UNLESS THE CLOSING RATE BAR IS SHOWN.	
14	AIRCRAFT VERIFICATION FAILURE	
	During entry into the Stand, the aircraft geometry is being checked.	(STOP)
	If, for any reason, aircraft verification is not made 12 meters before the stop-position, the display will first show WAIT and make a second verification check. If this fails STOP and ID FAIL will be displayed.	
	THE PILOT MUST NOT PROCEED BEYOND THE BRIDGE WITHOUT MANUAL GUIDANCE, UNLESS THE WAIT MESSAGE HAS BEEN SUPERSEDED BY THE CLOSING RATE BAR.	
15	TOO FAST	
	If the aircraft approaches with a speed higher than the docking	(CETOP)
	system can handle, the message STOP TOO FAST will be displayed. The docking system must be re-started or the docking procedure completed by manual guidance.	FAST

### **10 PBN procedures**

- 10.1 For RNAV(GNSS) SID and STAR aircraft must be approved by State of Registry in accordance with ICAO RNP1 standard or equivalent. Carriage of certified GNSS receiver is mandatory. Aircraft that do not have approval or whose RNP1/ P-RNAV capability has been degraded before departure shall use the Conventional Procedure.
- 10.2 To harmonize the implementation of PBN procedures, pilots of arriving aircraft to Macau International Airport are requested to report the type of approach on their initial contact with Macao ATC.

### 11 RNP AR approach

11.1 Special Authorization from AACM is required to conduct RNP AR APCH in Macao.

## VMMC AD 2.21 NOISE ABATEMENT PROCEDURES

The following procedures govern operations at Macau International Airport:

## **1** Noise abatement operating restrictions

### **1.1 Departing aircraft**

1.1.1 Take-off on runway 34 at any time

Climb offset 15° (right) to 400 ft (120 m), then turn RIGHT. Aircraft are NOT TO OVERSHOOT Jiuzhou DVOR (ZAO) R231° which defines the northern limit for flights taking off runway 34 due to NOISE ABATEMENT for Zhuhai City.

- 1.2 Arriving aircraft
- 1.2.1 Landing on runway 16 at any time

Maintain inbound track 215° (true north) on the localizer course. Aircraft are NOT TO DEVIATE FROM Jiuzhou DVOR (ZAO) R231° which defines the northern limit for flights landing runway 16 due to NOISE ABATEMENT for Zhuhai City.

1.3 Aircraft with ICAO Annex 16 Chapter 2 condition will only be considered in a case-by-case basis. For Chapter 2 noise aircraft, operation time between 00:00 - 08:00 local time is not allowed.

# 2 Aeroplane noise abatement operating procedures for take-off

NIL.

## 3 Training flight

3.1 Requests to carry out training flights, irrespective of the direction of landing and take-off, must be submitted in writing to the Chairman of Civil Aviation at least 24 hours in advance of any proposed training.

## 4 Engine tests and ground runs

Engine run-up are subject to the following conditions:

- 4.1 Normally engine runs above ground idle power are not permitted during the critical hours of 2200 to 0700 local time. Exception may be considered case by case, depending on actual operational analyses (e.g. time needed for engine run-up, expected movements, etc).
- 4.2 Engine Ground Run Procedures
- 4.2.1 An engine ground run is defined as any engine start up not associated with the planned aircraft departure. Maintenance or test running of jet engine not mounted on an aircraft is prohibited unless performed in a test cell of adequate design.
- 4.2.2 Normally, engine ground running at idle power for duration not exceeding 15 minutes may be conducted on aircraft parking bays with previous coordination with Airport Operation Coordination Centre (AOCC). Extension of such limitation is subject to AOCC approval depending on airport conditions. Power runs above idle for maintenance purpose must be conducted at designated areas.
- 4.2.3 Initial requests for a ground run at any time should be made by telephone to Airport Operation Coordination Centre. The airline or their representatives are responsible for ensuring that all safety precautions against injury to persons or damage to properties, aircraft, vehicles, marine vessels (when the jet blast is directed towards the sea) and equipment in the vicinity are adopted. When ready to conduct the engine run, clearance from Macau Ground on 121.725 MHz. A listening watch must be maintained on the frequency throughout the engine run. The aircraft anti-collision beacons must be activated for the entire duration and that Macau Ground should be advised on its completion.

# VMMC AD 2.22 FLIGHT PROCEDURES

#### See AD Charts

# VMMC AD 2.23 ADDITIONAL INFORMATION

### 1 Automatic Terminal Information Service (ATIS)

STATI	BROADCAST ON	HOURS	CONTENTS	REMARKS
ON	FREQUENCY			
MACAU Internation al Airport	126.4 MHz	24 hours	Continuous broadcast in voice by Aerodrome control: - Runway in use, - Surface wind, - Visibility, - Runway visual range when it is less than 1500m - Present weather - Cloud - Trend forecast - Aerodrome QNH, - Air temperature and Dew Point, - Any essential information considered to be useful to operation of aircraft e.g. low visibility operation in force, thunderstorms warnings, typhoon signal no. 8 or above, aerodrome surface conditions, unserviceability of navigation aids, type(s) of approach to be expected etc.	Pilots are required to acknowledge the identifier at first contact on the frequency of responsible approach control unit (Zhuhai APP 120.35 (123.85), Hong Kong radar 126.3 MHz and 119.1 MHz) if aircraft is arriving and on 118.0 / 121.725 MHz as appropriate (see AD 2.20) if aircraft is departing

## 2 GNSS RAIM Prediction Services and Associated NOTAM Information

GNSS RAIM availability prediction service and the associated NOTAM information related to GNSS availability will not be provided by AACM or Macau International Airport.

In accordance with ICAO Doc 9613, PBN Manual, aircraft operators shall subscribe the necessary information provided by other service providers to verify the RAIM availability for the intended route of flight.

Pages AD - VMMC - 27 to AD 2 - VMMC - 49 reserved for future development

# **INTENTIONALLY**

# LEFT

# **BLANK**


# VMMC AD 2.24 CHARTS RELATED TO AN AERODROME


	Page
Aerodrome Chart — ICAO	AD 2 - VMMC - 52
Aircraft Parking / Docking Chart — ICAO	AD 2 - VMMC - 53
Aerodrome Obstruction Chart (RWY 34) — ICAO	AD 2 - VMMC - 54
Aerodrome Obstruction Chart (RWY 16) — ICAO	AD 2 - VMMC - 55
Precision Approach Terrain Chart (RWY 34) — ICAO	AD 2 - VMMC - 56
Area Chart Macau ICAO	AD 2 - VMMC - 58
SID Macau RWY 34	AD 2 - VMMC - 59 to 62J
SID Macau RWY 16	AD 2 - VMMC - 63 to 64H
STAR Macau RWY 34	AD 2 - VMMC - 65 to 66D
STAR Macau RWY 16	AD 2 - VMMC - 67 to 68E
Instrument Approach Charts — ICAO	AD 2 - VMMC - 69 to 72
Visual Approach Chart — ICAO	AD 2 - VMMC - 73
Visual Landing Chart — ICAO	AD 2 - VMMC - 74

# **AERONAUTICAL CHARTS**

## 1 Introduction

Data are compiled from different sources. As exhaustive verification is not possible within limits of resources, it is not possible to guarantee absolute accuracy of all data shown on charts except on MACAU Special Administrative Region.






# **INTENTIONALLY**

# LEFT

# **BLANK**



AD 2 - VMMC - 54

LIMITS ON ACCORDANCE WITH ICAO PRESCRIPTIONS

----- OBSTACLES AREA

PLANE ( PROFILE PRESENTATION )

 $\bigcap$ 

AIRAC AMDT 02/17




AMENDMENT RECORD				
NO□	DATE	ENTERED		


AD 2 - VMMC - 55

04 JAN 2018

# MACAU AERODROME OBSTACLE CHART - ICAO TYPE A (OPERATING LIMITATIONS)

RWY 16





LIMITS ON ACCORDANCE WITH ICAO PRESCRIPTIONS


AMENDMENT RECORD				
NO	DATE	ENTERED		



# MACAU PRECISION APPROACH TERRAIN CHART-ICAO RWY 34

AD 2 -VMMC - 56

DIMENSIONS AND ELEVATIONS IN METRES 4 ╢ - Sea to 900 m -Nominal glide path 3° 2 18 14 1 -10 8 6 4 2 --2 -4 -6 WARNING 60 Tidal variations High water 10 20 30 500 40 Low water -8 L LEGEND BUILDING OR LARGE STRUCTURE CONTOUR \_2-



HORIZONTALE SCALE : 1: 2500 VERTICALE SCALE : 1: 500 CONTOURS AND HEIGHTS ARE RELATED TO THRESHOLD ELEVATION

CORRECTIONS : NIL.



AMENDMENT RECORD			
NO DATE ENTERED BY			

Navigation aids	Frequency	Coor	dinates
CH DME	1094 MHz/CH70X	22°13'10.35"N	114°01'48.20"E
CON DVOR/DME	113.0MHz/CH77X	23°35.3'N	113°35.2'E
GAOLAN NDB	UJ 204	21°55.2'N	113°17.6'E
LKC DVOR/DME	113.2MHz/CH79X	22°22'44.12''N	113°53'01.50"E
MCU DVOR/DME	116.4MHz/CH111X	22°08'08''N	113°35'52"E
NLG DVOR/DME	117.7MHz/CH124X	22°31.9'N	113°33.7'E
POU DVOR/DME	114.1MHz/CH88X	23°01.3'N	113°11.4'E
SANZAO NDB	U 272	21°59.3'N	113°21.3'E
SHL DVOR/DME	115.7MHz/CH104X	23°05.5'N	113°51.0'E
SMT DVOR/DME	114.8MHz/CH95X	22°20'15.43''N	113°58'55.46"E
TD DVOR/DME	116.1MHz/CH108X	22°14'52.42"N	114°17'35.30"E
ZAO DVOR/DME	117.2MHz/CH119X	22°14.7'N	113°36.7'E
ZUH DVOR/DME	116.7MHz/CH114X	22°13.3'N	113°28.0'E
CEN DVOR/DME	114.6MHz/CH93X	23°09.1'N	113°25.0'E

# 1. Navigation aids related to Macao Instrument Flight Procedures:

# 2. Way-Points related to Macao Instrument Flight Procedures:

Way-Point	Radial & Distance	Coo	ordinates
ALLEY	TD R205° DME 75.0	21°05'11.2"N	113°47'09.5"E
ATIKO		21 48 29.56N	113 32 26.04E
BIGRO		21°34.2'N	111°49.6'E
BOKAT		22°02.3'N	113°00.0'E
BREAM		21°46'46.00''N	114°03'28.00"E
BUMDI		22°21'39.62''N	114°18'52.61"E
CAMRI	LKC R156° DME 23.4	21°01'46.2"N	114°04'28.7"E
	SMT R167° DME 19.1		
CHALI		21°17'45.00"N	113°36'41.00"E
CONGA	TD R105° DME 142.3	21°44'02.5"N	116°47'05.9"E

		-	
DOCTA	LKC R168° DME 26.8	21°56'49.5"N	114°00'33.4"E
	SMT R179° DME 23.4		
FUSU	CON R191° DME 32.5	23°03.2'N	113°30.5'E
GRUPA	TD R135° DME 125.0	20°50'44.0"N	115°56'59.0"E
GURIN	MCU R246° DME 37.0	21°51.1'N	113°00.0'E
HAZEL	LKC R211° DME 24.0	22°01'26.49"N	113°40'56.63"E
IDUMA	GLN R341° DME 12.1	22°53.8'N	113°57.1'E
	SHL R157 ° DME 13.0		
INDUS		22°02'41.0"N	113°36'01.0"E
KIBAS	NLG R220° DME 29.5	22°08.3'N	113°14.5'E
	ZUH R250° DME 14.0		
LAKES	TD R118° DME 38.0	21°58'41.3"N	114°54'38.6"E
LATOP	MCU DME 9.0 ZAO R041°	22°16.9'N	113°38.6E
	NLG R167° DME 15.6		
MIPAG	GLN R311° DME 20.6	22° 55.3'N	113° 44.5'E
MULET	MCU R164° DME 35	21°35'02.0"N	113°47'52.0"E
OCEAN	TD R135° DME 39.0	21°48'43.0"N	114°48 48.0'E
Papa "P"	MCU R164° DME 10.0	21°58'39"N	113°39'22"E
PECAN	TD R200° DME 50.5	21°26'20.2''N	114°02'05.6"E
RASSE	TD R118° DME 63.9	21°47'34.5"N	115°19'49.1"E
Romeo "R"	MCU R209° DME 18.0	21°51.8'N	113°26.9'E
RUNLI		21°26'59.72"N	113°40'51.00"E
SAREX	POU R120° DME 18.2	22°52.9'N	113°29.0'N
	CON R191° DME 43.0		
SHELY	TD R118° DME 22.2	22°05'26.65"N	114°39'13.94''E
SKATE	TD R135° DME 64.0	21°31'55.0"N	115°08'40.0''E
SOUSA	TD R100° DME 106.6	22°01'10.4"N	116°11'27.8"E
TITAN	TD R205° DME 36.9	21°40'27.4''N	114°03'02.5"E
TUNNA	NLG R156° DME 49.7	21°47'25.0"N	113°57'54.0"E


Waypoint	Coordinates (WGS	84)
GLN	22°42′30.00″N	114°02′00.00″E
RW16	22°09′38.31″N	113°35′14.14″E
RW34	22°08′17.46″N	113°35′43.91″E
MC411	22°21′41.20″N	113°47′37.58″E
MC417	22°21′22.48″N	113°25′20.13″E
MC418	22°20′59.43″N	113°37′16.98″E
MC419	22°26′25.37″N	113°46′47.49″E
MC420	22°20′32.29″N	113°41′43.59″E
MC501	22°00′03.00″N	113°38′45.76″E
MC502	22°02′43.76″N	113°00′50.39″E
MC508	22°12′25.79″N	113°34′59.76″E
MC509	22°14′34.78″N	113°36′37.67″E
MC510	22°17′02.13″N	113°38′29.61″E
MC511	22°21′49.23″N	113°36′58.39″E
MC512	22°21′49.25″N	113°33′45.41″E
MC513	22°01′09.95″N	113°37′20.04″E
MC514	22°06′52.19″N	113°32′56.82″E
MC601	22°19′43.55″N	113°56′43.60″E
MC608	22°11′14.42″N	113°34′38.75″E
MC609	22°02′35.07″N	113°37′49.87″E
MC610	21°52′31.46″N	113°41′36.15″E
MC611	21°39′36.00″N	113°46′30.00″E
MC612	21°50′42.92″N	113°36′08.19″E
MC613	21°54′20.84″N	113°34′45.32″E
MC614	21°58′12.27″N	113°36′03.19″E
MC615	22°18′12.10″N	113°50′26.77″E

# 3. Way-Points related to Macao RNP Flight Procedures:


MC800	22°19'24.7490"N	113°37'43.8130"E
MC802	22°17'31.0330"N	113°38'19.5450"E
MC806	22°14'58.1330"N	113°37'25.5250"E
MC808	22°14'12.4680"N	113°36'21.1390"E
MC810	22°13'20.0870"N	113°35'07.3230"E
MC812	22°11'32.2130"N	113°34'32.1820"E
MC820	22°07'12.5500"N	113°36'07.8040"E
MC822	22°04'45.1840"N	113°37'02.0200"E
MCC80	22°16'51.1470"N	113°35'53.0160"E
MCC82	22°12'03.4710"N	113°36'10.0330"E
MCC84	22°02'24.8370"N	113°29'43.4130"E

# GUANGZHOU FIR - HONG KONG FIR

#### AREA CHART MACAO ICAO



RADIO FAILURE PROCEDURE : Squawk A / 7600



#### BIGRO 5 D (minimum climb gradient of 4.8% required until leaving 1800 m)

Depart on track 359°M and climb to at or above 400 ft (120 m). Then turn right and continue climb to ZAO. Leave ZAO on R041°. Turn left at LATOP to intercept SMT R275° at or above 1200 m. Then continue climbing, at NLG R215° turn left to intercept NLG R220° at or above 1800 m. To KIBAS at 2700 m, turn right at KIBAS on ZUH 250°M, to BOKAT at 3600 m, to BIGRO.

If ZAO is unserviceable, depart on track 359°M, at MCU DME 3.3NM turn right on track 041°M and continue climbing. Turn left at MCU DME 9.0NM to intercept SMT 275°M at or above 1200m. Then join original procedure.

#### MIPAG 1 E (minimum climb gradient of 4.8% required until leaving 4500m)

Depart on track 359°M and climb to at or above 400 ft (120 m). Then turn right and continue climb to ZAO. Leave ZAO on R041°. At LATOP turn right to proceed on ZAO R042° and continue climbing to 4500 m and maintain. At ZAO DME 36.3NM turn left to establish on CEN R131° to MIPAG at 4500m.

NLG 5 D (minimum climb gradient of 4.8% required until reaching 1500 m)

Depart on track 359°M and climb to at or above 400 ft (120 m). Then turn right and continue climb to ZAO. Leave ZAO on R041°. At LATOP turn left to establish on NLG R167° and reach 1500m by NLG.

If ZAO is unserviceable, depart on track 359°M, at MCU DME 3.3NM turn right on track 041°M and continue climbing. At MCU DME 9.0NM turn left to establish on NLG R167°M. Then join original procedure.

SHL 1 E (minimum climb gradient of 4.8% required until leaving 4500m)


Depart on track 359°M and climb to 400 ft (120 m). Then turn right and continue climb to ZAO. Leave ZAO on R041°. At LATOP turn right to proceed on ZAO R042° and continue climbing to 4500 m and maintain. At ZAO DME 36.3NM turn left on track 341°M to IDUMA at 4500m. Turn left at IDUMA and proceed to SHL via SHL R158°.

#### **REMARK:**

- (1) Aircraft are NOT TO OVERSHOOT JIUZHOU DVOR (ZAO 117.2 MHz) R231° which defines the northern limit for flights taking off RWY 34 due to NOISE ABATEMENT for Zhuhai City.
- (2) Aircraft unable to comply with the minimum climb gradient must inform Macao ground control at first contact to allow special coordination.
- (3) Maximum departure turning speed: 205 kt IAS.
- (4) Owing to the proximity of the Hong Kong international airport, pilots departing on RWY 34 towards Hong Kong direction are reminded the need to follow the standard SID track until LKC DVOR. Any deviation from the standard SID track could result in direct conflict with Hong Kong traffic.

AD2-VMMC-60 C 23 FEB 2023

# GUANG ZHOU FIR - HONG KONG FIR RNAV(GNSS) SID MACAO RWY 34 (BIGRO 7 D, MIPAG 7 D, NLG 7 D, SHL 7 D) CAT A, B, C, D



#### BIGRO 7 D (minimum climb gradient of 4.8% required until leaving 1800 m)

Climb on track 359°M, at 400 ft (120 m) turn right. Direct to LATOP, to MC418 at 1200m, turn left to MC417 at 1800 m, to KIBAS at 2700 m, to BOKAT at 3600 m and BIGRO.

#### MIPAG 7 D (minimum climb gradient of 4.8% required until leaving 4500m)

Climb on track 359°M, at 400 ft (120 m) turn right. Direct to LATOP, MC419, GLN, Turn left to MIPAG at 4500 m.

#### NLG 7 D (minimum climb gradient of 4.8% required until reaching 1500 m)

Climb on track 359°M, at 400 ft (120 m) turn right. Direct to LATOP, to MC418 at 1200m and to NLG at 1500m.

#### SHL 7 D (minimum climb gradient of 4.8% required until leaving 4500m)

Climb on track 359°M, at 400 ft (120 m) turn right. Direct to LATOP, MC419, GLN. Turn left to IDUMA at 4500 m and SHL.

#### **REMARK :**

- (1) For RNAV<sub>(GNSS)</sub> SID aircraft must be approved by State of Registry in accordance with ICAO RNP1 standard or equivalent. Carriage of certified GNSS receiver is mandatory.
- (2) Aircraft that do not have approval or whose RNP1/ P-RNAV capability has been degraded before departure shall use the Conventional Departure Procedure: BIGRO 5 D, MIPAG 5 D, NLG 5 D, SHL 5 D.
- (3) Aircraft are NOT TO OVERSHOOT JIUZHOU DVOR (ZAO 117.2 MHz) R231° which defines the northern limit for flights taking off RWY 34 due to NOISE ABATEMENT for Zhuhai City.
- (4) Aircraft unable to comply with the minimum climb gradient must inform Macao ground control at first contact to allow special coordination.
- (5) Maximum departure turning speed: 205 kt IAS.
- (6) Owing to the proximity of the Hong Kong international airport, pilots departing on RWY 34 towards Hong Kong direction are reminded the need to follow the standard SID track until LKC DVOR. Any deviation from the standard SID track could result in direct conflict with Hong Kong traffic.

## FMC Database Coding Reference for RNAV(GNSS) SIDs

#### BIGRO 7 D

l

Sequence	Path	Waymaint	Fly-	Track °M	Distance	Turn	Altitude	Speed
Number	Terminator	Waypoint	over	(°T)	(NM)	Dir	(ft)	(knot)
001	CA			359(356)			@ 400	-205
002	DF	LATOP		—		R		-205
003	TF	MC418		347(344)	4.3	_	@ 3900	
004	TF	MC417		275(272)	11		@ 5900	
005	TF	KIBAS		220(217)	16.6		@ 8900	
006	TF	BOKAT		250(247)	14.7		@ 11800	
007	TF	BIGRO		250(247)	71.3			
001	IF	BIGRO						_

#### MIPAG 7 D

Sequence	Path	Waypoint	Fly-	Track °M	Distance	Turn	Altitude	Speed
Number	Terminator	w aypoint	over	(°T)	(NM)	Dir	(ft)	(knot)
001	CA			359(356)			@ 400	-205
002	DF	LATOP		_		R		-205
003	TF	MC419		041(038)	12.0			
004	TF	GLN		044(041)	21.5			
005	TF	MIPAG		311(308)	20.5	L	@ 14800	

#### NLG 7 D


Sequence	Path	Waypoint	Fly-	Track °M	Distance	Turn	Altitude	Speed
Number	Terminator	waypoint	over	(°T)	(NM)	Dir	(ft)	(knot)
001	CA			359(356)			@ 400	-205
002	DF	LATOP		_		R		-205
003	TF	MC418		347(344)	4.3		@ 3900	
004	TF	NLG		347(344)	11.3		@ 4900	

#### SHL 7 D

Sequence	Path	Waymaint	Fly-	Track °M	Distance	Turn	Altitude	Speed
Number	Terminator	Waypoint	over	(°T)	(NM)	Dir	(ft)	(knot)
001	CA			359(356)			@ 400	-205
002	DF	LATOP				R		-205
003	TF	MC419		041(038)	12.0	—		—
004	TF	GLN		044(041)	21.5			
005	TF	IDUMA		341(338)	12.0		@ 14800	
006	TF	SHL		338(335)	13.1			

### Waypoint Coordinates

Waypoint Name	Coordinates (WGS84)					
LATOP	22°16.9′N	113°38.6′E				
MC418	22°20′59.43″N	113°37′16.98″E				
MC417	22°21′22.48″N	113°25′20.13″E				
KIBAS	22°08.3′N	113°14.5′E				
BOKAT	22°02.3′N	113°00.0′E				
NLG	22°31.9′N	113°33.7′E				
MC419	22°26′25.37″N	113°46′47.49″E				
MIPAG	22°55.3′N	113°44.5′E				
GLN	22°42.5′N	114°02.0′E				
IDUMA	22°53.8′N	113°57.1′E				
SHL	23°05.5′N 113°51.0′E					



Civil Aviation Authority - Macao, China

Update: Annotation of altitude

ALLEY 2 T (minimum climb gradient of 5.4% required until leaving 5500 ft) limb on track 359°M, at 400 ft (120 m) turn right. Direct to LATOP, turn right to MC420 at or above 4000 ft (1219m), to MC411 at or above 5500 ft (1676m), to LKC at 6000 ft. Further climb when instructed by ATC. To CAMRI, BREAM, TITAN, PECAN and ALLEY. Continue on Terminal Transition Routes published in Hong Kong AIP.

#### **CONGA 2 T** (minimum climb gradient of 5.4% required until leaving 5500 ft)

Climb on track 359°M, at 400 ft (120 m) turn right. Direct to LATOP, turn right to MC420 at or above 4000 ft (1219m), to MC411 at or above 5500 ft (1676m), to LKC at 6000 ft. Further climb when instructed by ATC. To TD, OCEAN, RASSE and CONGA. Continue on Terminal Transition Routes published in Hong Kong AIP.

GRUPA 2 T (minimum climb gradient of 5.4% required until leaving 5500 ft)

Climb on track 359°M, at 400 ft (120 m) turn right. Direct to LATOP, turn right to MC420 at or above 4000 ft (1219m), to MC411 at or above 5500 ft (1676m), to LKC at 6000 ft. Further climb when instructed by ATC. To TD, OCEAN and GRUPA. Continue on Terminal Transition Routes published in Hong Kong AIP.

**SOUSA 3 T** (minimum climb gradient of 5.4% required until leaving 5500 ft)

Climb on track 359°M, at 400 ft (120 m) turn right. Direct to LATOP, turn right to MC420 at or above 4000 ft (1219m), to MC411 at or above 5500 ft (1676m), to LKC at 6000 ft. Further climb when instructed by ATC. To TD, SHELY, LAKES and SOUSA. Continue on Terminal Transition Routes published in Hong Kong AIP.

#### **REMARK:**

- (1) For RNAV<sub>(GNSS)</sub> SID aircraft must be approved by State of Registry in accordance with ICAO RNP1 standard or equivalent. Carriage of certified GNSS receiver is mandatory.
- (2) Aircraft that do not have approval or whose RNP1/ P-RNAV capability has been degraded before departure shall use the <u>Conventional Departure Procedure</u>:

Depart on track 359°M and climb to 400 ft (120 m). Then turn right and continue climb to ZAO. Leave ZAO on R041° climbing to 4000 ft, at LKC DME11.5 (MCU DME 12.5) turn right to establish on LKC R261°, continue climbing to pass 5500 ft by LKC DME 5.0 and reach 6000 ft by LKC. Further climb when instructed by ATC. From LKC expect radar vectors to ALLEY, CONGA, GRUPA or SOUSA.

If ZAO is unserviceable, depart on track 359 °M, at MCU DME 3.3 turn right on track 041 °M. Then turn right by MCU DME 13.1(LKC DME 11.4) at altitude 4000ft to intercept LKC R261 °. Continue climbing to pass 5500ft by LKC DME 5.0 and reach 6000ft by LKC. Further climb when instructed by ATC. From LKC expect radar vectors to ALLEY, CONGA, GRUPA or SOUSA.

If LKC is not available, request ALLEY 1 V, CONGA 1 V, GRUPA 1 V or SOUSA 2 V.

- (3) Aircraft are NOT TO OVERSHOOT ZAO DVOR R231° which defines the northern limit for flights taking off RWY 34 due to NOISE ABATEMENT for Zhuhai City.
- (4) Procedure Design Gradient based only on airspace restriction.
- (5) Aircraft unable to comply with the minimum climb gradient must inform MACAO ground control at first contact to allow special coordination.
- (6) Maximum departure turning speed: 205 kt IAS until directing to LATOP.
- (7) Aircraft shall fly at 250 kt or less below FL 110 transiting Hong Kong Airspace
- (8) In the event of loss of communication, aircraft shall comply with the last acknowledged clearance up to the next reporting point in the SID, then climb to the flight planned cruising level and follow the flight planned route to join the appropriate airway.
- (9) Owing to the proximity of the Hong Kong International Airport, pilots departing on RWY 34 towards Hong Kong direction are reminded the need to follow the standard SID track until LKC DVOR. Any deviation from the standard SID track could result in direct conflict with Hong Kong traffic.

# AD2-VMMC-62 A 24 FEB 2022 GUANG ZHOU FIR – HONG KONG FIR (ALLEY 2T, CONGA 2T, GRUPA 2T, SOUSA 3T) CAT A, B, C, D

# FMC Database Coding Reference for RNAV(GNSS) SIDs

ALI	LEY 2 T								
	Sequence	Path	Waypoint	Fly-	Track °M	Distance	Turn	Altitude	Speed
	Number	Terminator	w aypoint	over	(°T)	(NM)	Dir	(ft)	(knot)
	001	CA		—	359 (356)			@ 400	-205
	002	DF	LATOP			_	R		-205
	003	TF	MC420	—	041(038)	5.0	—	+4000	—
	004	TF	MC411		081(078)	5.6	_	+5500	-250
	005	TF	LKC		081(078)	5.1	_	@ 6000	_
	006	TF	CAMRI		156(153)	23.4	R		
	007	TF	BREAM		187(184)	15.0	R		_
	008	TF	TITAN		187(184)	6.3			
	009	TF	PECAN		187(184)	14.1	_		_
	010	TF	ALLEY		217(214)	25.3	R		

#### CONGA 2 T

l

l

l

Sequence	Path	Waymaint	Fly-	Track °M	Distance	Turn	Altitude	Speed
Number	Terminator	Waypoint	over	(°T)	(NM)	Dir	(ft)	(knot)
001	CA			359 (356)			@ 400	-205
002	DF	LATOP	_	—		R		-205
003	TF	MC420		041(038)	5.0	—	+4000	—
004	TF	MC411	_	081(078)	5.6	_	+5500	-250
005	TF	LKC	_	081(078)	5.1	_	@ 6000	
006	TF	TD		112(109)	24.0	R		—
007	TF	OCEAN	_	135(132)	39.0	R		_
008	TF	RASSE		095(092)	28.9	L		
009	TF	CONGA		095(092)	81.3			

#### GRUPA 2 T


-								
Sequence	Path	Waypoint	Fly-	Track °M	Distance	Turn	Altitude	Speed
Number	Terminator	w aypoint	over	(°T)	(NM)	Dir	(ft)	(knot)
001	CA			359 (356)			@ 400	-205
002	DF	LATOP	_			R	—	-205
003	TF	MC420	_	041(038)	5.0		+4000	_
004	TF	MC411	_	081(078)	5.6		+5500	-250
005	TF	LKC	_	081(078)	5.1		@ 6000	_
006	TF	TD	_	112(109)	24.0	R		_
007	TF	OCEAN		135(132)	39.0	R		
008	TF	GRUPA	_	135(132)	86.0			

#### SOUSA 3 T

Sequence	Path	Waymaint	Fly-	Track °M	Distance	Turn	Altitude	Speed
Number	Terminator	Waypoint	over	(°T)	(NM)	Dir	(ft)	(knot)
001	CA	—		359 (356)			@ 400	-205
002	DF	LATOP	_	_		R	_	-205
003	TF	MC420	_	041(038)	5.0		+4000	_
004	TF	MC411		081(078)	5.6		+5500	-250
005	TF	LKC		081(078)	5.1	_	@ 6000	—
006	TF	TD		112(109)	24.0	R		
007	TF	SHELY		118(115)	22.2	R	—	—
008	TF	LAKES	_	118(115)	15.8	_		_
009	TF	SOUSA		091(088)	71.4	L		

### Waypoint Coordinates

Waypoint Name	Coordinates (WGS84)					
LATOP	22°16.9′N	113°38.6′E				
MC420	22°20′32.29″N	113°41′43.59″E				
MC411	22°21′41.20″N	113°47′37.58″E				
LKC	22°22′44″N	113°53′02″E				
TD	22°14′52.42″N	114°17′35.30″E				
SHELY	22°05′26.65″N	114°39′13.94″E				
LAKES	21°58′41.3″N	114°54′38.6″E				
SOUSA	22°01′10.4″N	116°11′27.8″E				
OCEAN	21°48′43.0″N	114°48′48.0″E				
RASSE	21°47′34.5″N	115°19′49.1″E				
CONGA	21°44′02.5″N	116°47′05.9″E				
GRUPA	20°50′44.0″N	115°56′59.0″E				
CAMRI	22°01′46.2″N	114°04′28.7″E				
BREAM	21°46′46.00″N	114°03′28.00″E				
TITAN	21°40′27.4″N	114°03′02.5″E				
PECAN	21°26′20.2″N	114°02′05.6″E				
ALLEY	21°05′11.2″N	113°47′09.5″E				



ALLEY 2 U (minimum climb gradient of 5.4% required until leaving 5500 ft) Climb on track 359°M, at 400 ft (120 m) turn right. Direct to LATOP, turn right to <u>MC420</u> at or above 4000 ft (1219m), to <u>MC411</u> at or above 5500 ft (1676m), to LKC at 6000 ft. Further climb when instructed by ATC. To DOCTA, BREAM, TITAN, PECAN and ALLEY. Continue on Terminal Transition Routes published on Hong Kong AIP.

### **CONGA 3 U** (minimum climb gradient of 5.4% required until leaving 5500 ft)

Climb on track 359°M, at 400 ft (120 m) turn right. Direct to LATOP, turn right to <u>MC420</u> at or above 4000 ft (1219m), to <u>MC411</u> at or above 5500 ft (1676m), to LKC at 6000 ft. Further climb when instructed by ATC. To <u>DOCTA</u> at or above FL 140, to OCEAN, RASSE and CONGA. Continue on Terminal Transition Routes published on Hong Kong AIP.

**GRUPA 3 U** (minimum climb gradient of 5.4% required until leaving 5500 ft)

Climb on track 359°M, at 400 ft (120 m) turn right. Direct to LATOP, turn right to <u>MC420</u> at or above 4000 ft (1219m), to <u>MC411</u> at or above 5500 ft (1676m), to LKC at 6000 ft. Further climb when instructed by ATC. To <u>DOCTA</u> at or above FL 140, to OCEAN and GRUPA. Continue on Terminal Transition Routes published in Hong Kong AIP.

### SOUSA 3 U (minimum climb gradient of 5.4% required until leaving 5500 ft)

Climb on track 359°M, at 400 ft (120 m) turn right. Direct to LATOP, turn right to <u>MC420</u> at or above 4000 ft (1219m), to <u>MC411</u> at or above 5500 ft (1676m), to LKC at 6000 ft. Further climb when instructed by ATC. To <u>DOCTA</u> at or above FL 140, to LAKES and SOUSA. Continue on Terminal Transition Routes published in Hong Kong AIP.

# **REMARK:**

- (1) For RNAV<sub>(GNSS)</sub> SID aircraft must be approved by State of Registry in accordance with ICAO RNP1 standard or equivalent. Carriage of certified GNSS receiver is mandatory.
- (2) Aircraft that do not have approval or whose RNP1/ P-RNAV capability has been degraded before departure shall use the <u>Conventional Departure Procedure</u>:

Depart on track 359°M and climb to 400 ft (120 m). Then turn right and continue climb to ZAO. Leave ZAO on R041° climbing to 4000 ft, at LKC DME 11.5 (MCU DME 12.5) turn right to establish on LKC R261°, continue climbing to pass 5500 ft by LKC DME 5.0 and reach 6000 ft by LKC. Further climb when instructed by ATC. From LKC expect radar vectors to ALLEY, CONGA, GRUPA or SOUSA.

If ZAO is unserviceable, depart on track 359 °M, at MCU DME 3.3 turn right on track 041 °M. Then turn right by MCU DME 13.1(LKC DME 11.4) at altitude 4000ft to intercept LKC R261 °. Continue climbing to pass 5500ft by LKC DME 5.0 and reach 6000ft by LKC. From LKC expect radar vectors to ALLEY, CONGA, GRUPA or SOUSA.

If LKC is not available, request ALLEY 1 W, CONGA 2 W, GRUPA 2 W, SOUSA 2 W.

- (3) Aircraft are NOT TO OVERSHOOT ZAO DVOR R231° which defines the northern limit for flights taking off RWY 34 due to NOISE ABATEMENT for Zhuhai City.
- (4) Procedure Design Gradient based only on airspace restriction.
- (5) Aircraft unable to comply with the minimum climb gradient must inform MACAO ground control at first contact to allow special coordination.
- (6) Maximum departure turning speed: 205 kt IAS until directing to LATOP.
- (7) Aircraft shall fly at 250 kt or less below FL 110 transiting Hong Kong Airspace
- (8) In the event of loss of communication, aircraft shall comply with the last acknowledged clearance up to the next reporting point in the SID, then climb to the flight planned cruising level and follow the flight planned route to join the appropriate airway.
- (9) Owing to the proximity of the Hong Kong International Airport, pilots departing on RWY 34 towards Hong Kong direction are reminded the need to follow the standard SID track until LKC. Any deviation from the standard SID track could result in direct conflict with Hong Kong traffic.

# AD2-VMMC-62 E GUANG ZHOU FIR – HONG KONG FIR 24 FEB 2022 RNAV<sub>(GNSS)</sub> SID MACAO RWY 34 (ALLEY 2 U, CONGA 3 U, GRUPA 3 U, SOUSA 3 U) CAT A, B, C, D

# FMC Database Coding Reference for RNAV(GNSS) SIDs

### ALLEY 2 U

1

I

l

Sequence	Path	Waynoint	Fly-	Track °M	Distance	Turn	Altitude	Speed
Number	Terminator	Waypoint	over	(°T)	(NM)	Dir	(ft)	(knot)
001	CA			359 (356)			@ 400	-205
002	DF	LATOP		—		R		-205
003	TF	MC420		041 (038)	5.0	_	+4000	
004	TF	MC411		081 (078)	5.6		+5500	-250
005	TF	LKC		081 (078)	5.1	_	@ 6000	
006	TF	DOCTA		168 (165)	26.8	R	—	
007	TF	BREAM		168 (165)	10.4		—	
008	TF	TITAN		187 (184)	6.3	R	—	
009	TF	PECAN		187 (184)	14.1			
010	TF	ALLEY		217 (214)	25.3	R	—	

# CONGA 3U (RWY34 SID)

Sequence	Path	Waypoint	Fly-	Track °M	Distance	Turn	Altitude	Speed
Number	Terminator	w aypoint	over	(°T)	(NM)	Dir	(ft)	(knot)
001	CA			359(356)			@ 400	-205
002	DF	LATOP				R	—	-205
003	TF	MC420		041(038)	5.0		+4000	
004	TF	MC411		081(078)	5.6		+5500	-250
005	TF	LKC		081(078)	5.1		@ 6000	
006	TF	DOCTA		168(165)	26.8	R	+FL140	
007	TF	OCEAN		103(100)	45.6	L		
008	TF	RASSE		095(092)	28.9	L		
009	TF	CONGA		095(092)	81.3			


# GRUPA 3U (RWY34 SID)

Sequence	Path	Waynoint	Fly-	Track °	Distance	Turn	Altitude	Speed
Number	Terminator	Waypoint	over	M (°T)	(NM)	Dir	(ft)	(knot)
001	CA			359(356)	—		@ 400	-205
002	DF	LATOP				R		-205
003	TF	MC420		041(038)	5.0		+4000	_
004	TF	MC411		081(078)	5.6		+5500	-250
005	TF	LKC		081(078)	5.1		@ 6000	_
006	TF	DOCTA		168(165)	26.8	R	+FL140	
007	TF	OCEAN		103(100)	45.6	L		
008	TF	GRUPA		135(132)	86.0	R		

# SOUSA 3U (RWY34 SID)

Sequence	Path	Waypoint	Fly-	Track °M	Distance	Turn	Altitude	Speed
Number	Terminator	waypoint	over	(°T)	(NM)	Dir	(ft)	(knot)
001	CA	—		359 (356)			@ 400	-205
002	DF	LATOP	—		_	R		-205
003	TF	MC420		041 (038)	5.0		+4000	_
004	TF	MC411	—	081 (078)	5.6		+5500	-250
005	TF	LKC		081 (078)	5.1		@ 6000	_
006	TF	DOCTA		168 (165)	26.8	R	+FL140	
007	TF	LAKES		091 (088)	50.3	L		
010	TF	SOUSA		091 (088)	71.4			

Waypoint Name		dinates GS84)
LATOP	22°16.9′N	113°38.6′E
MC420	22°20′32.29″N	113°41′43.59″E
MC411	22°21′41.20″N	113°47′37.58″E
LKC	22°22′44″N	113°53′02″E
DOCTA	21°56′49.5″N	114°00′33.4″E
LAKES	21°58′41.3″N	114°54′38.6″E
SOUSA	22°01′10.4″N	116°11′27.8″E
OCEAN	21°48′43.0″N	114°48′48.0″E
RASSE	21°47′34.5″N	115°19′49.1″E
CONGA	21°44′02.5″N	116°47′05.9″E
GRUPA	20°50′44.0″N	115°56′59.0″E
BREAM	21°46′46.00″N	114°03′28.00″E
TITAN	21°40′27.4″N	114°03′02.5″E
PECAN	21°26′20.2″N	114°02′05.6″E
ALLEY	21°05′11.2″N	113°47′09.5″E



# GUANG ZHOU FIR – HONG KONG FIR SID MACAO RWY 34 (ALLEY 1 V, CONGA 1 V, GRUPA 1 V, SOUSA 2 V) CAT A, B, C, D

# ALLEY 1 V (minimum climb gradient of 5.4% required until leaving 5500 ft)

Depart on track 359°M and climb to 400 ft (120 m). Then turn right and continue climb to ZAO. Leave ZAO on R041° climbing to 4000 ft, at SMT DME 16.1 (MCU DME 12.5) turn right to establish on SMT R275°, continue climbing to pass 5500 ft by SMT DME 11.0 and reach 6000 ft by SMT DME 6.0. Further climb when instructed by ATC. From SMT DME 6.0 turn right to CAMRI. From CAMRI turn right direct to BREAM, then TITAN and then PECAN. From PECAN turn right to ALLEY. Continue on Terminal Transition Routes published in Hong Kong AIP.

### If SMT is not available, ALLEY 1 V is not permitted.

**CONGA 1 V** (minimum climb gradient of 5.4% required until leaving 5500 ft)

Depart on track 359°M and climb to 400 ft (120 m). Then turn right and continue climb to ZAO. Leave ZAO on R041° climbing to 4000 ft, at SMT DME 16.1 (MCU DME 12.5) turn right to establish on SMT R275°, continue climbing to pass 5500 ft by SMT DME 11.0 and reach 6000 ft by SMT DME 6.0. Further climb when instructed by ATC. From SMT track direct to TD. From TD track direct to OCEAN and then turn left direct to RASSE and CONGA. Continue on Terminal Transition Routes published in Hong Kong AIP.

# If SMT is not available, CONGA 1 V is not permitted.

If TD is not available, expect radar vectors to CONGA.

### GRUPA 1 V (minimum climb gradient of 5.4% required until leaving 5500 ft)

Depart on track 359°M and climb to 400 ft (120 m). Then turn right and continue climb to ZAO. Leave ZAO on R041° climbing to 4000 ft, at SMT DME 16.1 (MCU DME 12.5) turn right to establish on SMT R275°, continue climbing to pass 5500 ft by SMT DME 11.0 and reach 6000 ft by SMT DME 6.0. Further climb when instructed by ATC. From SMT track direct to TD. From TD track direct to OCEAN and then GRUPA. Continue on Terminal Transition Routes published in Hong Kong AIP.

If SMT is not available, GRUPA 1 V is not permitted If TD is not available, expect radar vectors to GRUPA.

SOUSA 2 V (minimum climb gradient of 5.4% required until leaving 5500 ft)

Depart on track 359°M and climb to 400 ft (120 m). Then turn right and continue climb to ZAO. Leave ZAO on R041° climbing to 4000 ft, at SMT DME 16.1 (MCU DME 12.5) turn right to establish on SMT R275°, continue climbing to pass 5500 ft by SMT DME 11.0 and reach 6000 ft by SMT DME 6.0. Further climb when instructed by ATC. From SMT track direct to TD. From TD turn right direct to SHELY then LAKES. From LAKES turn left direct to SOUSA. Continue on Terminal Transition Routes published in Hong Kong AIP.

If SMT is not available, SOUSA 2 V is not permitted. If TD is not available, expect radar vectors to SHELY.

## **REMARK:**

- (1) Aircraft are NOT TO OVERSHOOT JIUZHOU DVOR (ZAO 117.2 MHz) R231° which defines the northern limit for flights taking off RWY 34 due to NOISE ABATEMENT for Zhuhai City.
- (2) Procedure Design Gradient based only on airspace restriction.
- (3) Aircraft unable to comply with the minimum climb gradient must inform MACAO ground control at first contact to allow special coordination.
- (4) Maximum departure turning speed: 205 kt IAS until ZAO DVOR.
- (5) Standard Instrument Departure Procedures (SIDs) transiting Hong Kong Airspace Speed Restriction

Aircraft shall fly at 250 kt or less below FL 110.

Loss of communication

In the event of loss of communication, aircraft shall comply with the last acknowledged clearance up to the next reporting point in the SID, then climb to the flight planned cruising level and follow the flight planned route to join the appropriate airway.


- (6) Owing to the proximity of the Hong Kong international airport, pilots departing on RWY 34 towards Hong Kong direction are reminded the need to follow the standard SID track until LKC DVOR. Any deviation from the standard SID track could result in direct conflict with Hong Kong traffic.
- (7) If ZAO is unserviceable, Depart on track 359°M, at MCU DME 3.3NM turn right on track 041°M. Then turn right by MCU DME 13.8NM (SMT DME 16.2NM) at altitude 4000ft to intercept SMT R275°, continue climbing to pass 5500ft by SMT DME 11.0NM and reach 6000ft by SMT DME 6.0NM. Further climb when instructed by ATC and continues the original SID.

# AD2-VMMC-62 I

# 27 JAN 2022

# GUANG ZHOU FIR - HONG KONG FIR SID MACAO RWY 34 (ALLEY 1 W, CONGA 2 W, GRUPA 2 W, SOUSA 2 W)

CAT A, B, C, D



# GUANG ZHOU FIR – HONG KONG FIR SID MACAO RWY 34 (ALLEY 1 W, CONGA 2 W, GRUPA 2 W, SOUSA 2 W) CAT A, B, C, D

### **ALLEY 1 W** (minimum climb gradient of 5.4% required until leaving 5500 ft)

Depart on track 359°M and climb to 400 ft (120 m). Then turn right and continue climb to ZAO. Leave ZAO on R041° climbing to 4000 ft, at SMT DME 16.1 (MCU DME 12.5) turn right to establish on SMT R275°, continue climbing to pass 5500 ft by SMT DME 11.0 and reach 6000 ft by SMT DME 6.0. Further climb when instructed by ATC. From SMT DME 6.0 turn right to DOCTA and then BREAM. From BREAM turn right direct to TITAN and then PECAN. From PECAN turn right to ALLEY. Continue on Terminal Transition Routes published on Hong Kong AIP.

### If SMT is not available, ALLEY 1 W is not permitted.

**CONGA 2 W** (minimum climb gradient of 5.4% required until leaving 5500 ft)

Depart on track 359°M and climb to 400 ft (120 m). Then turn right and continue climb to ZAO. Leave ZAO on R041° climbing to 4000 ft, at SMT DME 16.1 (MCU DME 12.5) turn right to establish on SMT R275°, continue climbing to pass 5500 ft by SMT DME 11.0 and reach 6000 ft by SMT DME 6.0. Further climb when instructed by ATC. At SMT DME 6.0 turn right direct to DOCTA. Expect to cross DOCTA FL140 or above. From DOCTA turn left direct to OCEAN then turn left direct to RASSE and CONGA. Continue on Terminal Transition Routes published in Hong Kong AIP.

## If SMT is not available, CONGA 2 W is not permitted.

### GRUPA 2 W (minimum climb gradient of 5.4% required until leaving 5500 ft)

Depart on track 359°M and climb to 400 ft (120 m). Then turn right and continue climb to ZAO. Leave ZAO on R041° climbing to 4000 ft, at SMT DME 16.1 (MCU DME 12.5) turn right to establish on SMT R275°, continue climbing to pass 5500 ft by SMT DME 11.0 and reach 6000 ft by SMT DME 6.0. Further climb when instructed by ATC. At SMT DME 6.0 turn right direct to DOCTA. Expect to cross DOCTA FL140 or above. From DOCTA turn left direct to OCEAN then turn right direct to GRUPA. Continue on Terminal Transition Routes published in Hong Kong AIP.

## If SMT is not available, GRUPA 2 W is not permitted.

## SOUSA 2 W (minimum climb gradient of 5.4% required until leaving 5500 ft)

Depart on track 359°M and climb to 400 ft (120 m). Then turn right and continue climb to ZAO. Leave ZAO on R041° climbing to 4000 ft, at SMT DME 16.1 (MCU DME 12.5) turn right to establish on SMT R275°, continue climbing to pass 5500 ft by SMT DME 11.0 and reach 6000 ft by SMT DME 6.0. Further climb when instructed by ATC. At SMT DME 6.0 turn right direct to DOCTA. Expect to cross DOCTA FL140 or above. From DOCTA turn left direct to LAKES and SOUSA. Continue on Terminal Transition Routes published in Hong Kong AIP.

## If SMT is not available, SOUSA 2 W is not permitted.

#### **REMARK:**


- (1) Aircraft are NOT TO OVERSHOOT JIUZHOU DVOR (ZAO 117.2 MHz) R231° which defines the northern limit for flights taking off RWY 34 due to NOISE ABATEMENT for Zhuhai City.
- (2) Procedure Design Gradient based only on airspace restriction.
- (3) Aircraft unable to comply with the minimum climb gradient must inform MACAO ground control at first contact to allow special coordination.
- (4) Maximum departure turning speed: 205 kt IAS until ZAO DVOR.
- (5) Standard Instrument Departure Procedures (SIDs) transiting Hong Kong Airspace Speed Restriction

Aircraft shall fly at 250 kt or less below FL 110.

Loss of communication

In the event of loss of communication, aircraft shall comply with the last acknowledged clearance up to the next reporting point in the SID, then climb to the flight planned cruising level and follow the flight planned route to join the appropriate airway.

- (6) Owing to the proximity of the Hong Kong international airport, pilots departing on RWY 34 towards Hong Kong direction are reminded the need to follow the standard SID track until LKC DVOR. Any deviation from the standard SID track could result in direct conflict with Hong Kong traffic.
- (7) If ZAO is unserviceable, Depart on track 359°M, at MCU DME 3.3NM turn right on track 041°M. Then turn right by MCU DME 13.8NM (SMT DME 16.2NM) at altitude 4000ft to intercept SMT R275°, continue climbing to pass 5500ft by SMT DME 11.0NM and reach 6000ft by SMT DME 6.0NM. Further climb when instructed by ATC and continues the original SID.



AIRAC AMDT 02/22

### BIGRO 3 D (minimum climb gradient of 3.8% required until leaving 1500 m)

Climb straight ahead to cross MCU DME 8.5 at 2000 ft (610 m) or above, then turn right on track 283°M, continue climbing and pass Sanzao beacon (U 272 kHz) at 1500 m. Climb on track 282°M and establish on ZUH R250° towards BIGRO, pass BOKAT at 3600 m.

If MCU is unserviceable, climb straight ahead to cross ZAO DME 14.8 NM at 2000 ft (610 m) or above then turn right on track 283 °M. Then join original procedure.

# MIPAG 1 F (minimum climb gradient of 3.8% required until leaving 2400 m)

Climb straight ahead to cross MCU DME 8.5 at 2000 ft (610 m) or above, then turn right to MCU via MCU R197° and cross MCU at 1800 m. Leave MCU on R020° and continue climbing to 2400 m, at LATOP turn right to establish on ZAO R042°. Continue climbing on ZAO R042° to 4500 m and maintain. At ZAO DME 36.3NM turn left to establish on CEN R131° to MIPAG at 4500m.

If MCU is unserviceable, climb straight ahead to cross ZAO DME 14.8 NM at 2000 ft (610 m) or above then turn right to ZAO via ZAO R195°M and cross ZAO DME 6.7 NM at 1800 m, leave ZAO on R041°M and cross 2400 m by LATOP. Then join original procedure.

### NLG 9 D (minimum climb gradient of 3.8% required until reaching 2400 m)

Climb straight ahead to cross MCU DME 8.5 at 2000 ft (610 m) or above, then turn right to MCU via MCU R197° and cross MCU at 1800 m. Leave MCU on R020° and reach 2400 m by LATOP. At LATOP turn left to establish NLG R167 <sup>°</sup> and descend to reach 1500m by NLG.

If MCU is unserviceable, climb straight ahead to cross ZAO DME 14.8 NM at 2000 ft (610 m) or above then turn right to ZAO via ZAO R195°M and cross ZAO DME 6.7 NM at 1800 m, leave ZAO on R041°M and cross 2400 m by LATOP. Then join original procedure.

#### SHL 1 F (minimum climb gradient of 3.8% required until leaving 2400 m)

Climb straight ahead to cross MCU DME 8.5 at 2000 ft (610 m) or above, then turn right to MCU via MCU R197° and cross MCU at 1800 m. Leave MCU on R020° and continue climbing to 2400 m, at LATOP turn right to establish on ZAO R042°. Continue climbing on ZAO R042° to 4500 m and maintain. At ZAO DME 36.3NM turn left on track 341° M to IDUMA at 4500m. Turn left at IDUMA and proceed to SHL via SHL R158°.

If MCU is unserviceable, climb straight ahead to cross ZAO DME 14.8 NM at 2000 ft (610 m) or above then turn right to ZAO via ZAO R195°M and cross ZAO DME 6.7 NM at 1800 m, leave ZAO on R041°M and cross 2400 m by LATOP. Then join original procedure.

## **REMARK:**

- (1) Aircraft unable to comply with the minimum climb gradient must inform MACAO ground control at first contact to allow special coordination.
- (2) Maximum departure turning speed: 205 kt IAS.

# **INTENTIONALLY**

# LEFT

# **BLANK**


# **INTENTIONALLY**

# LEFT

# **BLANK**

# AD2-VMMC-64 A 23 FEB 2023

# GUANG ZHOU FIR - HONG KONG FIR RNAV(GNSS) SID MACAO RWY 16 (BIGRO 2 D, MIPAG 2 D, NLG 2 D, SHL 2 D) CAT A, B, C, D



# BIGRO 2 D (minimum climb gradient of 3.8% required until leaving 1500 m)

Depart and Climb to fly-over <u>MC501</u> on course 164°M at 2000 ft (610 m) or above, then turn right to Sanzao beacon (U 272 kHz) at 1500 m on course 283°M. To MC502 at 3600 m and to BIGRO.

### MIPAG 2 D (minimum climb gradient of 3.8% required until leaving 2400 m)

Depart and Climb to fly-over <u>MC501</u> on course 164° M at 2000 ft (610 m) or above, then turn right direct to MCU at 1800 m. to LATOP at 2400m, to MC419, GLN, MIPAG at 4500 m.

### NLG 2 D (minimum climb gradient of 3.8% required until reaching 2400 m)

Depart and Climb to fly-over <u>MC501</u> on course 164° M at 2000 ft (610 m) or above, then turn right direct to MCU at 1800 m. to LATOP at 2400m, and to NLG at 1500m.

### SHL 2 D (minimum climb gradient of 3.8% required until leaving 2400 m)

Depart and Climb to fly-over <u>MC501</u> on course 164°M at 2000 ft (610 m) or above, then turn right direct to MCU at 1800 m. to LATOP at 2400m, to MC419, GLN, IDUMA at 4500 m and to SHL.

### **REMARK :**

- (1) For RNAV<sub>(GNSS)</sub> SID aircraft must be approved by State of Registry in accordance with ICAO RNP1 standard or equivalent. Carriage of certified GNSS receiver is mandatory.
- (2) Aircraft that do not have approval or whose RNP1/ P-RNAV capability has been degraded before departure shall use the Conventional Departure Procedure: BIGRO 3 D, NLG 9 D, SHL 9 D, MIPAG 9 D.
- (3) Aircraft unable to comply with the minimum climb gradient must inform MACAO ground control at first contact to allow special coordinations.
- (4) Maximum departure turning speed: 205 kt IAS.

# FMC Database Coding Reference for RNAV(GNSS) SIDs

### **BIGRO 2 D**

Sequence	Path	Waypoint	Fly-	Track °M	Distance	Turn	Altitude	Speed
Number	Terminator	waypoint	over	(°T)	(NM)	Dir	(ft)	(knot)
001	CF	MC501	Y	164 (161)	8.6		+2000	-205
002	CF	U		283(280)		R	@ 4900	-205
003	TF	MC502		283(280)	19	_	@ 11800	-
004	TF	BIGRO		250(247)	72.1			

# MIPAG 2 D

Sequence	Path	Waypoint	Fly-	Track °M	Distance	Turn	Altitude	Speed
Number	Terminator	waypoint	over	(°T)	(NM)	Dir	(ft)	(knot)
001	CF	MC501	Y	164 (161)	8.6	—	+2000	-205
002	DF	MCU				R	@ 5900	-205
003	TF	LATOP		019(016)	9		@ 7900	-
004	TF	MC419		041(038)	12	—		-
005	TF	GLN		044(041)	22			-
006	TF	MIPAG		311(308)	20.5	L	@ 14800	


## NLG 2D

Sequence	Path	Waynaint	Fly-	Track °M	Distance	Turn	Altitude	Speed
Number	Terminator	Waypoint	over	(°T)	(NM)	Dir	(ft)	(knot)
001	CF	MC501	Y	164 (161)	8.6		+2000	-205
002	DF	MCU				R	@ 5900	-205
003	TF	LATOP		019(016)	9		@ 7900	
004	TF	NLG		346(343)	15.6		@ 4900	—

# SHL 2D

Sequence	Path	Waynaint	Fly-	Track °M	Distance	Turn	Altitude	Speed
Number	Terminator	Waypoint	over	(°T)	(NM)	Dir	(ft)	(knot)
001	CF	MC501	Y	164 (161)	8.6		+2000	-205
002	DF	MCU				R	@ 5900	-205
003	TF	LATOP		019(016)	9		@ 7900	-
004	TF	MC419		041(038)	12			-
005	TF	GLN		044(041)	22			-
006	TF	IDUMA		341(338)	12.0		@ 14800	
007	TF	SHL		338(335)	13.1			—

Waypoint Name		dinates 3884)
MC501	22°00′03.00″N	113°38′45.76″E
U	21°59.3′N	113°21.3′E
MC502	22°02′43.76″N	113°00′50.39″E
BIGRO	21°34.2′N	111°49.6′E
LATOP	22°16.9′N	113°38.6′E
NLG	22°31.9′N	113°33.7′E
MC419	22°26′25.37″N	113°46′47.49″E
GLN	22°42.5′N	114°02.0′E
IDUMA	22°53.8′N	113°57.1′E
SHL	23°05.5′N	113°51.0′E
MIPAG	22°55.3′N	113°44.5′E



Civil Aviation Authority - Macao, China

Update: Annotation of altitude.

AIRAC AMDT 01/21

# ALLEY 2 P

Climb on track 164°M to PAPA at not above 4000 ft. Expect further climb when instructed by ATC. To MULET and ALLEY. Continue on Terminal Transition route published in Hong Kong AIP.

## CONGA 2 P

Climb on track 164°M to PAPA at not above 4000 ft. Expect further climb when instructed by ATC. To MULET, SKATE and CONGA. Continue on Terminal Transition Routes published in Hong Kong AIP.

### GRUPA 2 P

Climb on track 164°M to PAPA at not above 4000 ft. Expect further climb when instructed by ATC. To MULET, SKATE and GRUPA. Continue on Terminal Transition Routes published in Hong Kong AIP.

### SOUSA 2 P

Climb on track 164°M to PAPA at not above 4000 ft. Expect further climb when instructed by ATC. To MULET, SKATE and SOUSA. Continue on Terminal Transition Routes published in Hong Kong AIP.

## **REMARK:**

- (1) For RNAV<sub>(GNSS)</sub> SID aircraft must be approved by State of Registry in accordance with ICAO RNP1 standard or equivalent. Carriage of certified GNSS receiver is mandatory.
- (2) Aircraft that do not have approval or whose RNP1/ P-RNAV capability has been degraded before departure shall use the <u>Conventional Departure Procedure</u>:

Proceed on MCU R164° to PAPA not above 4000 ft. Further climb when instructed by ATC. From PAPA expect radar vectors to ALLEY, CONGA, GRUPA or SOUSA.

If MCU is unserviceable, Climb straight ahead not above 4000 ft, track direct to MULET and expect radar vectors to ALLEY, CONGA, GRUPA or SOUSA.

- (3) Aircraft are NOT TO OVERSHOOT JIUZHOU DVOR (ZAO 117.2 MHz) R231° which defines the northern limit for flights taking off RWY 34 due to NOISE ABATEMENT for Zhuhai City.
- (4) Aircraft unable to comply with the minimum climb gradient must inform MACAO ground control at first contact to allow special coordination.
- (5) Aircraft shall fly at 250 kt or less below FL 110 transiting Hong Kong Airspace
- (6) In the event of loss of communication, aircraft shall comply with the last acknowledged clearance up to the next reporting point in the SID, then climb to the flight planned cruising level and follow the flight planned route to join the appropriate airway.

# FMC Database Coding Reference for RNAV(GNSS) SIDs

## ALLEY 2 P

ſ	Sequence	Path	Waypoint	Fly-	Track °M	Distance	Turn	Altitude	Speed
	Number	Terminator	waypoint	over	(°T)	(NM)	Dir	(ft)	(knot)
	001	CA			164 (161)			+420	
	002	CF	PAPA		164 (161)	10.0		-4000	-250
	003	TF	MULET		164 (161)	25.0		—	
ſ	004	TF	ALLEY		184 (181)	29.7	R		

# SOUSA 2 P (RWY16 SID)

Sequence	Path	Waypoint	Fly-	Track °M	Distance	Turn	Altitude	Speed
Number	Terminator	waypoint	over	(°T)	(NM)	Dir	(ft)	(knot)
001	CA			164 (161)			+420	
002	CF	PAPA		164 (161)	10.0		-4000	-250
003	TF	MULET		164 (161)	25.0			
004	TF	SKATE		095 (092)	75.3	L		
005	TF	SOUSA		065 (063)	65.3	L		

# CONGA 2 P (RWY16 SID)

Sequence	Path	Waypoint	Fly-	Track °M	Distance	Turn	Altitude	Speed
Number	Terminator	waypoint	over	(°T)	(NM)	Dir	(ft)	(knot)
001	CA			164 (161)			+420	
002	CF	PAPA		164 (161)	10.0		-4000	-250
003	TF	MULET	—	164(161)	25.0		—	
004	TF	SKATE		095(092)	75.3	L		
005	TF	CONGA		085(082)	92.5			

# GRUPA 2 P (RWY16 SID)


Sequence	e Path	Warmaint	Fly-	Track °M	Distance	Turn	Altitude	Speed
Numbe	r Terminator	Waypoint	over	(°T)	(NM)	Dir	(ft)	(knot)
001	CA			164 (161)			+420	
002	CF	PAPA		164 (161)	10.0		-4000	-250
003	TF	MULET		164 (161)	25.0			
004	TF	SKATE		095 (092)	75.3	L		
005	TF	GRUPA		135 (132)	61.0	R		

Waypoint Name		ordinates /GS84)
MC501	22°00′03.00″N	113°38′45.76″E
MULET	21°35′02.0″N	113°47′52.0″E
ALLEY	21°05′11.2″	113°47′09.5″E
SKATE	21°31′55.0″N	115°08′40.0″E
SOUSA	22°01′10.4″N	116°11′27.8″E
CONGA	21°44′02.5″N	116°47′05.9″E
GRUPA	20°50′44.0″N	115°56′59.0″E

AD2-VMMC-65 23 FEB 2023

# GUANG ZHOU FIR - HONG KONG FIR STAR MACAO RWY 34 (BIGRO 6 A, CON 6 A, NLG 5 A, POU 6 A) CAT A, B, C, D

**AIP MACAO** 



Civil Aviation Authority - Macao, China CORRECTION: NLG and MCU heading in Procedure AIRAC AMDT 02/22

# BIGRO 6 A

Proceed from BIGRO to UJ. Cross GURIN at 2700 m and cross UJ at 2700 m.

### CON 6 A

Descend on CON 191°M and cross FUSU at 3600 m or above, cross SAREX at 3300 m. At SAREX turn left to establish on NLG R351° to cross NLG. Leave NLG at NLG R167° to cross LATOP at 2400 m, then proceed on MCU R020° to cross MCU at 2100 m.

If MCU is unserviceable, from original procedure, to NLG. Leave NLG at R174°M to ZAO, track on ZAO R184°M, cross ZAO DME 6.7 NM at 2100m.

### NLG 5A

Leave NLG on NLG R167° to cross LATOP at 2400 m, then proceed on MCU R020° to cross MCU at 2100 m.

If MCU is unserviceable, leave NLG at R174°M to ZAO, track on ZAO R184°M, cross ZAO DME 6.7 NM at 2100m.

### POU 6 A

Descend on POU R120° to cross SAREX at 3300 m. At SAREX turn right to establish on NLG R351° to cross NLG. Leave NLG at NLG R167° to cross LATOP at 2400 m, then proceed on MCU R020° to cross MCU at 2100 m.

If MCU is unserviceable, from original procedure, to NLG. Leave NLG at R174°M to ZAO, track on ZAO R184°M, cross ZAO DME 6.7 NM at 2100m.

### **REMARK:**

- (1) Maximum approach turning speed: 190 kt IAS
- (2) Standard Arrival Routes (STARS) to MIA Transiting Hong Kong Airspace
  - Speed control
    - (a) Speed control shall be in force unless other wise advised.
    - (b) Aircraft on STAR clearance shall fly at not more than 250 kt IAS whilst they are below FL 110.
  - Loss of communication

In the event of loss of communication, aircraft shall comply with the specified STAR procedure, then join the ILS approach to Macao RWY 34.

# **INTENTIONALLY**

# LEFT

# **BLANK**


# **INTENTIONALLY**

# LEFT

# **BLANK**

# AD2-VMMC-66 A 23 FEB 2023

# GUANG ZHOU FIR - HONG KONG FIR RNAV(GNSS) STAR MACAO RWY 34 (BIGRO 7 A, NLG 7 A, POU 8 A) CAT A, B, C, D



Update: Magnetic track in procedure.

# **BIGRO 7 A**

From BIGRO to GURIN at 2700 m, to UJ at 2700 m.

# NLG7A

From NLG to LATOP at 2400 m, to MCU at 2100 m.

# POU 8 A

From POU to SAREX at 3300 m, to NLG, then to LATOP at 2400 m, to MCU at 2100 m.

## **REMARK:**

- (1) For RNAV<sub>(GNSS)</sub> STAR aircraft must be approved by State of Registry in accordance with ICAO RNP1 standard or equivalent. Carriage of certified GNSS receiver is mandatory.
- (2) Aircraft that do not have approval or whose RNP1/ P-RNAV capability has been degraded shall use the <u>Conventional Procedure</u>: BIGRO 6 A, NLG 5 A, POU 6 A.
- (3) Maximum approach turning speed: 190 kt IAS
- (4) Loss of communication In the event of loss of communication, aircraft shall comply with the specified

In the event of loss of communication, aircraft shall comply with the specified STAR procedure, then join the Macao RWY 34approach.

# FMC Database Coding Reference for RNAV(GNSS) STARs

# BIGRO 7A

1	GRU /A								
	Sequence	Path	Waypoint	Fly-	Track M	Distance	Turn	Altitude	Speed
	Number	Terminator	w aypoint	over	( T)	(NM)	Dir	(ft)	(knot)
	001	IF	BIGRO		—	—			_
	002	TF	GURIN		078(075)	67.7	—	@ 8900	_
	003	TF	UJ		078(075)	16.7		@ 8900	—

# NLG 7A (RWY34 STAR)

Sequence	Path	Waymaint	Fly-	Track M	Distance	Turn	Altitude	Speed
Number	Terminator	Waypoint	over	(T)	(NM)	Dir	(ft)	(knot)
001	IF	NLG						_
002	TF	LATOP		167(164)	15.6		@ 7900	_
003	TF	MCU		200(197)	9.1		@ 6900	—

### POU 8A

Sequence	Path	Waynoint	Fly-	Track M	Distance	Turn	Altitude	Speed
Number	Terminator	Waypoint	over	( ግ)	(NM)	Dir	(ft)	(knot)
001	IF	POU	—	_		—	+10800	-
002	TF	SAREX		120(117)	18.2	—	@10800	-
003	TF	NLG		171(168)	21.5			-
004	TF	LATOP		167(164)	15.6	—	@ 7900	-
005	TF	MCU		200(197)	9.1		@ 6900	_

Waypoint Name		linates 884)
BIGRO	21°34.2'N	111°49.6'E
GURIN	21°51.1'N	113°00.0'E
UJ	21°55.2'N	113°17.6'E
POU	23°01.3'N	113°11.4'E
SAREX	22°52.9'N	113°29.0'E
NLG	22°31.9'N	113°33.7'E
LATOP	22°16.9'N	113°38.6'E
MCU	22°08'08"N	113°35'52"E

# AD2-VMMC-66 C 27 JAN 2022

# GUANG ZHOU FIR - HONG KONG FIR RNAV(GNSS) STAR MACAO RWY 34 (CHALI 4 A, SMT 4 A) CAT A, B, C, D



TWR : MACAO Tower 118.0 APP : Zhuhai Approach 120.35 / 123.85 (1) APP : HONG KONG Radar 126.3 / 119.1 (2) ATIS : MACAO 126.4 TA 9000ft(2700m) VAR 3°W (2016) BUMDI A 269° MC601 258 NOT TO SCALE SIUMOTO 089 114.8 SMT FL190 CH 95X N22 20 15 E113 58 55 1 min MAX IAS 220kt CINT AR ŝ IAF(1) HAZE FL11( PAPA 3AA 3000(900m) 司 1 min MAX IAS 190kt ATIKO 5000 MC611 IAF(1) 1 min MAX IAS 6000<sup>°</sup>ft 210kt CHALI 44 RUNLI 9000 9000 1 min CHALI 074° FL110 MAX IAS 230kt 3000ft <sup>∞</sup> 4100ft (900m) ↓°(1250m) (900m) 091°→ARP ← 271 MAX APCH TURNING SPEED: 190kt IAS 2700ft (800m) BEARINGS, TRACKS AND RADIALS ARE MAGNETIC ALTITUDES AND ELEVATIONS ARE IN FEET AND (METERS/m). DISTANCES IN NAUTICAL MILES MSA 25NM

# CHALI 4 A

Leave CHALI at FL 110, Turn left to RUNLI at 9000 ft, to MC611 at or above 6000 ft descending to 3000ft. **DO NOT DESCEND WITHOUT ATC CLEARANCE.** 

### Note:

Conventional procedure decommissioned. Aircraft that do not have approval or whose RNP1/ P-RNAV capability has been degraded shall report to HK ATC and expect radar vector from HK ATC.

### SMT 4 A

Leave SMT to MC601, turn left to HAZEL at FL 110. DO NOT DESCEND WITHOUT ATC CLEARANCE.

#### Conventional Procedure

Leave SMT on R258°. At SMT DME 2.1 turn left track direct to HAZEL. Cross HAZEL at FL 110.

### **REMARK:**

- (1) For RNAV<sub>(GNSS)</sub> STAR aircraft must be approved by State of Registry in accordance with ICAO RNP1 standard or equivalent. Carriage of certified GNSS receiver is mandatory.
- (2) Aircraft that do not have approval or whose RNP1/ P-RNAV capability has been degraded shall use the <u>Conventional Procedure</u>.
- (3) Maximum approach turning speed: 190 kt IAS
- (4) Standard Arrival Routes (STARS) to MIA Transiting Hong Kong Airspace

# Speed control

Speed control shall be in force unless otherwise advised. Aircraft on STAR clearance shall fly at not more than 250 kt IAS whilst they are below FL 110.

Loss of communication

In the event of loss of communication, aircraft shall comply with the specified STAR procedure, then join the Macao RWY 34 approach.

Holding

The holding patterns for CHALI STAR are established at CHALI, PAPA and ATIKO. The holding patterns for SMT STAR are established at BUMDI, PAPA and ATIKO. In the event of holding, each flight will be instructed individually. In order to provide traffic management flexibility, traffic may be instructed to hold at other terminal holding (see HK AIP) as directed by ATC.

## FMC Database Coding Reference for RNAV(GNSS) STARs


## CHALI 4 A

Sequence Number	Path Terminator	Waypoint	Fly- over	Track °M (°T)	Distance (NM)	Turn Dir	Altitude (ft)	Speed (knot)
001	IF	CHALI					@FL110	
002	TF	RUNLI		026(023)	10.0		@9000	
003	TF	MC611		026(023)	13.5		+6000	

SMT 4 A

Sequence	Path	Waynoint	Fly-	Track °M	Distance	Turn	Altitude	Speed
Number	Terminator	Waypoint	over	(°T)	(NM)	Dir	(ft)	(knot)
001	IF	SMT		_				_
002	TF	MC601		258(255)	2.1			_
003	TF	HAZEL		222(219)	23.4	L	@FL110	_

Waypoint Name	Coordinate	s (WGS84)	Waypoint Name	Coordinates (WGS84)		
CHALI	21°17'45.00"N	113°36'41.00"E	HAZEL	22°01'26.49"N	113°40'56.63"E	
RUNLI	21°26'59.72"N	113°40'51.00"E	ATIKO	21°48'29.56"N	113°32'26.04"E	
MC611	21°39'36.00"N	113°46'30.00"E	BUMDI	22°21'39.62"N	114°18'52.61"E	
SMT	22°20'15.43"N	113°58'55.46"E	PAPA	21°58'39"N	113°39'22"E	
MC601	22°19'43.55"N	113°56'43.60"E				



AIRAC AMDT 01/21

# BIGRO 9 A

Proceed from BIGRO to UJ and cross GURIN at 2700 m. Leave UJ at 2700 m and turn left to establish on ZUH R211° to cross ZUH at 1800 m.

# CON 9 A

Descend on CON 191°M and cross FUSU at 3600 m or above, cross SAREX at 3300 m. At SAREX turn left to establish on NLG R351° to cross NLG at 2100 m.

### POU 9 A


Descend on POU R120° to cross SAREX at 3300 m. At SAREX turn right to establish on NLG R351° to cross NLG at 2100 m.

### **REMARK:**

(1) Maximum approach turning speed: 190 kt IAS

AD2-VMMC-68 A 27 JAN 2022

# GUANG ZHOU FIR - HONG KONG FIR RNAV(GNSS) STAR MACAO RWY 16 (BIGRO 1 A, POU 1 A) CAT A, B, C, D



# **BIGRO 1 A**

From BIGRO to GURIN at 2700 m., to UJ at 2700 m and to ZUH at 1800 m .

### POU 1 A

From POU to SAREX 3300 m, to NLG at 2100 m.

# **REMARK :**

- (1) For RNAV<sub>(GNSS)</sub> STAR aircraft must be approved by State of Registry in accordance with ICAO RNP1 standard or equivalent. Carriage of certified GNSS receiver is mandatory.
- (2) Aircraft that do not have approval or whose RNP1/P-RNAV capability has been degraded shall use the <u>Conventional Procedure:</u> BIGRO 9 A or POU 9 A.
- (3) Maximum approach turning speed: 190 kt IAS
- (4) Loss of communication: In the event of loss of communication, aircraft shall comply with the specified STAR procedure, then join the Macao RWY 16 approach.

# FMC Database Coding Reference for RNAV(GNSS) STARs

# **BIGRO 1A**

Sequence	Path	Warmaint	Fly-	Track °M	Distance	Turn	Altitude	Speed
Number	Terminator	Waypoint	over	(°T)	(NM)	Dir	(ft)	(knot)
001	IF	BIGRO		_				_
002	TF	GURIN		078(075)	67.7		@8900	_
003	TF	UJ		078(075)	16.7		@8900	_
004	TF	ZUH		031(028)	20.5		<i>@</i> 5900	_

## POU 1A


$\sim$									
	Sequence	Path	Waypoint	Fly-	Track °M	Distance	Turn	Altitude	Speed
	Number	Terminator	waypoint	over	(°T)	(NM)	Dir	(ft)	(knot)
	001	IF	POU					+10800	_
	002	TF	SAREX		120(117)	18.2		@10800	_
	003	TF	NLG		171(168)	21.5		@6900	_

Waypoint Name	Coordinates (WGS84)					
POU	23°01.3′N	113°11.4′E				
SAREX	22°52.9′N	113°29.0′E				
NLG	22°31.9′N	113°33.7′E				
BIGRO	21°34.2′N	111°49.6′E				
GURIN	21°51.1′N	113°00.0′E				
UJ	21°55.2′N	113°17.6′E				
ZUH	22°13.3′N	113°28.0′E				

AD2-VMMC-68 C 27 JAN 2022

# GUANG ZHOU FIR - HONG KONG FIR RNAV(GNSS) STAR MACAO RWY 16 (CHALI 5 B, SMT 5 B) CAT A, B, C, D

AIP MACAO



Civil Aviation Authority - Macao, China

Update: Annotation of altitude.

# CHALI 5 B

Descend from CHALI at FL 110, Turn left to RUNLI at 9000 ft. Turn left to MC513, to INDUS at 2700m, to MC514 at 2100 m and to ZUH at 1800 m. **DO NOT DESCEND WITHOUT ATC CLEARANCE.** 

Note:

Conventional procedure decommissioned. Aircraft that do not have approval or whose RNP1/ P-RNAV capability has been degraded shall report to HK ATC and expect radar vector from HK ATC.

### SMT 5 B

Leave SMT to MC601. Turn left to HAZEL at FL110 (3353m). Turn right to MC513, to INDUS at 2700 m, to MC514 at 2100 m and to ZUH at 1800 m. **DO NOT DESCEND WITHOUT ATC CLEARANCE.** 

#### Conventional Procedure

Leave SMT on R258 °. At SMT DME 2.1 turn left track direct to HAZEL. Cross HAZEL at FL 110. Turn right track direct to INDUS at 2700 m, cross ZUH DME 8.0 at 2100 and cross ZUH at 1800 m.

## **REMARK :**

- (1) For RNAV<sub>(GNSS)</sub> STAR aircraft must be approved by State of Registry in accordance with ICAO RNP1 standard or equivalent. Carriage of certified GNSS receiver is mandatory.
- (2) Aircraft that do not have approval or whose RNP1/ P-RNAV capability has been degraded shall use the <u>Conventional Procedure</u>:
- (3) Maximum approach turning speed: 190 kt IAS
- (4) Standard Arrival Routes (STARS) to MIA Transiting Hong Kong Airspace

Speed control

Speed control shall be in force unless otherwise advised. Aircraft on STAR clearance shall fly at not more than 250 kt IAS whilst they are below FL 110.

#### Loss of communication

In the event of loss of communication, aircraft shall comply with the specified STAR procedure, then join the Macao RWY 16 approach.

#### Holding

The holding patterns for CHALI STAR are established at CHALI, MC513 and ATIKO. The holding patterns for SMT STAR are established at BUMDI, MC513 and ATIKO. In the event of holding, each flight will be instructed individually. In order to provide traffic management flexibility, traffic may be instructed to hold at other terminal holding (see HK AIP) as directed by ATC.

# AD2-VMMC-68 E 27 JAN 2022

# GUANG ZHOU FIR – HONG KONG FIR STAR<sub>(GNSS)</sub> MACAO RWY 16 (CHALI 5 B, SMT 5 B) CAT A, B, C, D

# FMC Database Coding Reference for RNAV(GNSS) STARs

				0			,		
CHALI 5 B									
	Sequence	Path	Waymaint	Fly-	Track °M	Distance	Turn	Altitude	Speed
	Number	Terminator	Waypoint	over	(°T)	(NM)	Dir	(ft)	(knot)
	001	IF	CHALI					@FL110	—
	002	TF	RUNLI		026(023)	10	L	@9000	—
	003	TF	MC513		358(355)	34.2	L		—
	004	TF	INDUS		328(325)	1.9		@8900	—
	005	TF	MC514		328(325)	5.1		@6900	—
	006	TF	ZUH		328(325)	8		@5900	—

## SMT 5 B

Sequence Number	Path Terminator	Waypoint	Fly- over	Track °M (°T)	Distance (NM)	Turn Dir	Altitude (ft)	Speed (knot)
001	IF	SMT	_					-
002	TF	MC601		258(255)	2			_
003	TF	HAZEL		222(219)	23.4	L	@FL110	_
004	TF	MC513		268(265)	3.4	R		_
005	TF	INDUS		328(325)	1.9	R	@8900	_
006	TF	MC514		328(325)	5.1		@6900	_
007	TF	ZUH		328(325)	8		@5900	_

Waypoint Name	Coord (WG		Waypoint Name	Coordinates (WGS84)				
itume	(	561)	Itume	(110504)				
CHALI	21°17′45.00″N	113°36′41.00″E	SMT	22°20′15″N	113°58′55″E			
RUNLI	21°26′59.72″N	113°40′51.00″E	MC601	22°19′43.55″N	113°56′43.60″E			
MC513	22°01′09.95″N	113°37′20.04″E	HAZEL	22°01′26.49″N	113°40′56.63″E			
INDUS	22°02′41.0″N	113°36′01.0″E	ATIKO	21°48′29.56″N	113°32′26.04″E			
MC514	22°06′52.19″N	113°32′56.82″E	BUMDI	22°21'39.62″N	114°18′52.61″E			
ZUH	22°13.3′N	113°28.0′E						

# INSTRUMENT APPROACH

HEIGHTS RELATED TO AD. ELEV 20 ( 1 hPa)

CHART - ICAO

ATIS MACAO: 126.4 APP : ZHUHAI Approach 120.35 / 123.85 (1) HONG KONG Radar 126.3 / 119.1(2) TWR : MACAO Tower 118.0 MACAO Ground 121.725 / 121.975

27 JAN 2022


### AD 2 - VMMC - 69

ILS z RWY 34

ILS MCN 109.7 RDH: 54

PROTECTED FOR A B C D CAT

MAX APCH TURNING SPEED : 190 kt IAS MAX MISSED APCH TURNING SPEED : 185 kt IAS



**CIVIL AVIATION AUTHORITY- MACAO, CHINA** 


UPDATE : Annotation of altitude.

AIRAC AMDT 01/21

# **INTENTIONALLY**

# LEFT

# **BLANK**



**CIVIL AVIATION AUTHORITY- MACAO, CHINA** 

**CORRECTION : Coordinates of IAF(1).** 

## LEFT

INSTRUMENT APPROACH CHART - ICAO HEIGHTS RELATED TO AD. ELEV 20 ( 1 hPa)


ATIS MACAO: 126.4 APP : ZHUHAI Approach 120.35 / 123.85 (1) HONG KONG Radar 126.3 / 119.1(2) TWR : MACAO Tower 118.0

#### AD 2 - VMMC - 69B **RNP RWY 34**

PROTECTED FOR A B C D CAT MACAO Ground 121.725 / 121.975

27 JAN 2022

Minimum Temperature:+5°C MAX APCH TURNING SPEED : 190 kt IAS MAX MISSED APCH TURNING SPEED : 185 kt IAS



**UPDATE : Annotation of altitude.** 

Nr.         Terminator         Waypoint         MAP         over         (°T)         (NM)         Dir         (ft)         (knot)         TCH         Specification           001         IF         PAPA         -         -         -         -         -         03000         -190         -         RNP APCH           002         TF         MC609         F         -         344(341)         4.2         -         @1985         -190         3.00         RNP APCH           003         TF         RW34         M         Y         344(341)         6.0         -         +570         185         3.00         RNP APCH           004         TF         MC608         -         -         032(029)         4.0         -         -         -         RNP APCH           006         TF         LATOP         -         -         041(038)         2.7         -         -         -         RNP APCH           008         TF         MC411         -         -         041(038)         4.7         R         +3900         -         -         RNP APCH           009         TF         MC615         -         -         110(208)	G	5.1	1		-	<b>T</b> 1.01 <i>(</i>		-		a 1	TIDA	
Nr.         Terminator         MAP         over         (1)         (RM)         Dir         (R)         (R)         ICH         Specification           001         IF         PAPA         —         —         —         — $=$ <	Seq.	Path	Waypoint	FAF	Fly-	Track °M	Distance	Turn	Altitude	Speed	VPA/	Navigation
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$			• •	MAP	over	("1")	(NM)	Dır		· /	TCH	
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$												
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$						· · · ·						
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$				M	Y	· · · /		—			3.00	
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$								—	+600		—	
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$						· · · ·				-185	—	
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$				—		· · · ·				—		
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$						· · · /		R				
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	008		MC411			081(078)	5.6	—	+5500	—		RNP APCH
011         TF         PAPA         -         -         211(208)         3.1         -         -         -         -         RNP APCH           012         HM         PAPA         -         Y         344(341)         -         -         +3000         -185         -         RNP APCH           001         IF         MCU         -         -         -         -         -         RNP APCH           002         TF         MC614         -         -         182(179)         9.9         -         -         -         RNP APCH           003         TF         MC613         -         -         200(197)         4.0         -         -         -         RNP APCH           004         TF         MC612         -         -         164(161)         3.8         -         -         -         RNP APCH           005         TF         MC610         -         073(070)         5.4         -         -         RNP APCH           006         TF         PAPA         -         344(341)         6.5         -         @3000         -190         -         RNP APCH           002         TF         MC610	009		MC615	—		146(143)	4.4	—	+5500	—		RNP APCH
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	010	TF	HAZEL			211(208)	18.9					RNP APCH
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	011	TF	PAPA			211(208)	3.1					RNP APCH
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	012	HM	PAPA		Y	344(341)			+3000	-185		RNP APCH
003         TF         MC613         —         —         200(197)         4.0         —         —         —         —         MNP APCH           004         TF         MC612         —         —         164(161)         3.8         —         —         —         —         RNP APCH           005         TF         MC610         —         —         073(070)         5.4         —         —         —         —         RNP APCH           006         TF         PAPA         —         —         344(341)         6.5         —         @3000         -190         —         RNP APCH           001         IF         MC611         —         —         —         —         —         —         —         RNP APCH           002         TF         MC610         —         —         344(341)         13.7         —         —         —         RNP APCH           003         TF         PAPA         —         —         344(341)         6.5         —         @3000         -190         —         RNP APCH           001         IF         UJ         —         —         —         —         @8900         —	001	IF	MCU						@6900	—		RNP APCH
004         TF         MC612         —         —         Image: MC610         MC611         MC611         MC611         MC611         MC610         MC612         MC613         MC613         MC613         MC613         MC612         MC613         MC612         MC613         MC612         MC613         MC612         MC612         MC613	002	TF	MC614			182(179)	9.9					RNP APCH
004         TF         MC612         —         —         Image: MC610         MC611         MC610         MC700         MC610         MC700         MC610         MC700	003	TF	MC613			200(197)	4.0					RNP APCH
006         TF         PAPA         —         —         344(341)         6.5         —         @ 3000         -190         —         RNP APCH           001         IF         MC611         —         —         —         —         —         —         —         RNP APCH           002         TF         MC610         —         —         344(341)         13.7         —         —         —         RNP APCH           003         TF         PAPA         —         —         344(341)         6.5         —         @ 3000         -190         —         RNP APCH           001         IF         PAPA         —         —         344(341)         6.5         —         @ 3000         -190         —         RNP APCH           001         IF         UJ         —         —         —         —         @ 3000         -190         —         RNP APCH           002         TF         ROMEO         —         —         115(112)         9.4         —         @ 5900         —         —         RNP APCH           003         TF         MC612         —         —         100(097)         8.6         —         —	004	TF	MC612			164(161)	3.8		_			
001         IF         MC611         —         —         —         —         —         +6000         —         —         RNP APCH           002         TF         MC610         —         —         344(341)         13.7         —         —         —         RNP APCH           003         TF         PAPA         —         —         344(341)         6.5         —         @3000         -190         —         RNP APCH           001         IF         UJ         —         —         —         —         @3000         -190         —         RNP APCH           001         IF         UJ         —         —         —         —         @3000         -190         —         RNP APCH           002         TF         ROMEO         —         —         115(112)         9.4         —         @5900         —         —         RNP APCH           003         TF         MC612         —         —         100(097)         8.6         —         —         —         RNP APCH           004         TF         MC610         —         —         073(070)         5.4         —         —         —         RNP APC	005	TF	MC610			073(070)	5.4		_			RNP APCH
001         IF         MC611         —         …<	006	TF	PAPA			344(341)	6.5		@3000	-190		RNP APCH
002         TF         MC610         —         —         344(341)         13.7         —         —         —         —         RNP APCH           003         TF         PAPA         —         —         344(341)         6.5         —         @3000         -190         —         RNP APCH           001         IF         UJ         —         —         —         —         @8900         —         —         RNP APCH           002         TF         ROMEO         —         —         115(112)         9.4         —         @5900         —         —         RNP APCH           003         TF         MC612         —         —         100(097)         8.6         —         —         —         RNP APCH           004         TF         MC610         —         —         073(070)         5.4         —         —         —         RNP APCH           005         TF         PAPA         —         —         343(341)         6.5         —         @3000         -190         —         RNP APCH           001         IF         HAZEL         —         —         —         —         @3000         -190	001	IF	MC611						+6000			
003         TF         PAPA         —         —         344(341)         6.5         —         @ 3000         -190         —         RNP APCH           001         IF         UJ         —         —         —         —         @ 8900         —         —         RNP APCH           002         TF         ROMEO         —         —         115(112)         9.4         —         @ 5900         —         —         RNP APCH           003         TF         MC612         —         —         100(097)         8.6         —         —         —         RNP APCH           004         TF         MC610         —         —         073(070)         5.4         —         —         —         RNP APCH           005         TF         PAPA         —         —         343(341)         6.5         —         @ 3000         -190         —         RNP APCH           005         TF         PAPA         —         —         343(341)         6.5         —         @ 3000         -190         —         RNP APCH           001         IF         HAZEL         —         —         —         —         @ 93000         -190 </td <td>002</td> <td>TF</td> <td></td> <td></td> <td></td> <td>344(341)</td> <td>13.7</td> <td></td> <td></td> <td></td> <td></td> <td></td>	002	TF				344(341)	13.7					
001         IF         UJ         —         —         —         —         —         @ 8900         —         —         RNP APCH           002         TF         ROMEO         —         —         115(112)         9.4         —         @ 5900         —         —         RNP APCH           003         TF         MC612         —         —         100(097)         8.6         —         —         —         RNP APCH           004         TF         MC610         —         —         073(070)         5.4         —         —         —         RNP APCH           005         TF         PAPA         —         —         343(341)         6.5         —         @ 3000         -190         —         RNP APCH           001         IF         HAZEL         —         —         —         —         —         —         RNP APCH           001         IF         HAZEL         —         —         —         @ @ Slow         -         —         RNP APCH           002         TF         MC613         —         —         222(219)         9.1         —         —         —         RNP APCH           00						· · · ·			@3000	-190		
002         TF         ROMEO         —         —         115(112)         9.4         —         @ 5900         —         —         RNP APCH           003         TF         MC612         —         —         100(097)         8.6         —         —         —         RNP APCH           004         TF         MC610         —         —         073(070)         5.4         —         —         —         RNP APCH           005         TF         PAPA         —         —         0343(341)         6.5         —         @ 3000         -190         —         RNP APCH           001         IF         HAZEL         —         —         —         —         @ @ S000         -190         —         RNP APCH           001         IF         HAZEL         —         —         —         —         @ @ S000         -190         —         RNP APCH           002         TF         MC613         —         —         222(219)         9.1         —         —         —         RNP APCH           003         TF         MC612         —         —         164(161)         3.8         —         —         —         —	001	IF	UJ						@8900			RNP APCH
003         TF         MC612         —         —         IO0(097)         8.6         —         —         —         RNP APCH           004         TF         MC610         —         —         073(070)         5.4         —         —         —         —         RNP APCH           005         TF         PAPA         —         —         343(341)         6.5         —         @3000         -190         —         RNP APCH           001         IF         HAZEL         —         —         —         —         @6100         —         RNP APCH           002         TF         MC613         —         —         —         —         @7100         Statistics         #         MP APCH           003         TF         MC612         —         —         164(161)         3.8         —         —         —         RNP APCH           004         TF         MC610         —         —         073(070)         5.4         —         —         —         RNP APCH	002	TF	ROMEO			115(112)	9.4		@5900			RNP APCH
004         TF         MC610         —         —         073(070)         5.4         —         —         —         —         RNP APCH           005         TF         PAPA         —         —         343(341)         6.5         —         @3000         -190         —         RNP APCH           001         IF         HAZEL         —         —         —         —         @FL110         —         —         RNP APCH           002         TF         MC613         —         —         222(219)         9.1         —         —         —         RNP APCH           003         TF         MC612         —         —         164(161)         3.8         —         —         —         RNP APCH           004         TF         MC610         —         —         073(070)         5.4         —         —         —         RNP APCH	003	TF	MC612			· · · ·	8.6					RNP APCH
005         TF         PAPA         —         343(341)         6.5         —         @3000         -190         —         RNP APCH           001         IF         HAZEL         —         —         —         —         @65         —         @3000         -190         —         RNP APCH           001         IF         HAZEL         —         —         —         —         @65L110         —         —         RNP APCH           002         TF         MC613         —         —         222(219)         9.1         —         —         —         RNP APCH           003         TF         MC612         —         —         164(161)         3.8         —         —         —         RNP APCH           004         TF         MC610         —         —         073(070)         5.4         —         —         —         RNP APCH		TF				· · · /						
001         IF         HAZEL         —         —         —         —         @FL110         —         —         RNP APCH           002         TF         MC613         —         —         222(219)         9.1         —         —         —         RNP APCH           003         TF         MC612         —         —         164(161)         3.8         —         —         —         RNP APCH           004         TF         MC610         —         —         073(070)         5.4         —         —         —         RNP APCH									@3000	-190		
002         TF         MC613         —         —         222(219)         9.1         —         —         —         RNP APCH           003         TF         MC612         —         —         164(161)         3.8         —         —         —         RNP APCH           004         TF         MC610         —         —         073(070)         5.4         —         —         —         RNP APCH												
003         TF         MC612         —         —         Image: MC612						222(219)						
004 TF MC610 — — 073(070) 5.4 — — — RNP APCH						· /						
						· /						
Ι UOΣ Ι ΙΕ Ι ΡΑΡΑ Ι — Ι — Ι 344(341) Ι 6.Σ Ι — Ι (@3000) Ι -190 Ι — Ι RNPAPCH	005	TF	PAPA			344(341)	6.5		@3000	-190		RNP APCH

### FMC Database Coding Reference for RNP RWY34 APCH

#### Waypoint Coordinates

Waypoint			Waypoint		
Name	Coordinates	(WGS84)	Name	Coordinates	(WGS84)
HAZEL	22°01'26.49"N	113°40'56.63"E	MC613	21°54'20.84"N	113°34'45.32"E
LATOP	22°16.9'N	113°38.6'E	MC614	21°58'12.27"N	113°36'03.19"E
MC411	22°21'41.20"N	113°47'37.58"E	MC615	22°18'12.10"N	113°50'26.77"E
MC420	22°20'32.29"N	113°41'43.59"E	MCU	22°08'08"N	113°35'52"E
MC608	22°11'14.42"N	113°34'38.75"E	PAPA	21°58'39"N	113°39'22"E
MC609	22°02'35.07"N	113°37'49.87"E	ROMEO	21°51.8'N	113°26.9'E
MC610	21°52'31.46"N	113°41'36.15"E	RW34	22°08'17.46"N	113°35'43.91"E
MC611	21°39'36.00"N	113°46'30.00"E	UJ	21°55.2'N	113°17.6'E
MC612	21°50'42.92"N	113°36'08.19"E	ZAO	22°14.7'N	113°36.7'E

#### INSTRUMENT APPROACH CHART - ICAO

HEIGHTS RELATED TO AD. ÉLEV 20 ( 1 hPa)


ATIS MACAO : 126.4 APP : ZHUHAI Approach 120.35 / 123.85 (1) HONG KONG Radar 126.3 / 119.1(2) TWR : MACAO Tower 118.0 MACAO Ground 121.725 / 121.975

27 JAN 2022

#### AD 2 - VMMC - 69 D ILS x RWY 34 RNAV(GNSS)

ILS MCN 109.7

PROTECTED FOR A B C D CAT RDH: 54 MAX APCH TURNING SPEED : 190 kt IAS MAX MISSED APCH TURNING SPEED : 185 kt IAS



**CIVIL AVIATION AUTHORITY- MACAO, CHINA** 

UPDATE: Annotation of altitude.

AIRAC AMDT 01/21

~	~ -						-		~ .		
Seq.	Path	Waypoint	FAF	Fly-	Track °M	Distance	Turn	Altitude	Speed	VPA/	Navigation
Nr.	Terminator	waypoint	MAP	over	(°T)	(NM)	Dir	(ft)	(knot)	TCH	Specification
001	IF	MCU						@6900			RNP APCH
002	TF	MC614			182(179)	9.9				—	RNP APCH
003	TF	MC613			200(197)	4.0				—	RNP APCH
004	TF	MC612			164(161)	3.8		—			RNP APCH
005	TF	MC610			073(070)	5.4		—			RNP APCH
006	TF	PAPA			344(341)	6.5		@3000	-190		RNP APCH
001	IF	MC611						+6000			RNP APCH
002	TF	MC610			344(341)	13.7					RNP APCH
003	TF	PAPA			344(341)	6.5		@3000	-190		RNP APCH
001	IF	UJ						@8900			RNP APCH
002	TF	ROMEO			115(112)	9.4		@5900			RNP APCH
003	TF	MC612			100(097)	8.6					RNP APCH
004	TF	MC610			073(070)	5.4					RNP APCH
005	TF	PAPA			344(341)	6.5		@3000	-190		RNP APCH
001	IF	HAZEL						@FL110			RNP APCH
002	TF	MC613			222(219)	9.1					RNP APCH
003	TF	MC612			164(161)	3.8					RNP APCH
004	TF	MC610			073(070)	5.4					RNP APCH
005	TF	PAPA		_	344(341)	6.5		@3000	-190	—	RNP APCH

### FMC Database Coding Reference for ILS x RWY 34

#### Waypoint Coordinates

Waypoint Name	Coordinates (WGS84)				
HAZEL	22°01'26.49"N	113°40'56.63"E			
LATOP	22°16.9'N	113°38.6'E			
MC610	21°52'31.46"N	113°41'36.15"E			
MC611	21°39'36.00"N	113°46'30.00"E			
MC612	21°50'42.92"N	113°36'08.19"E			
MC613	21°54'20.84"N	113°34'45.32"E			
MC614	21°58'12.27"N	113°36'03.19"E			
MC615	22°18'12.10"N	113°50'26.77"E			
MCU	22°08'08"N	113°35'52"E			
PAPA	21°58'39"N	113°39'22"E			
ROMEO	21°51.8'N	113°26.9'E			
UJ	21°55.2'N	113°17.6'E			

#### INSTRUMENT APPROACH CHART - ICAO

HEIGHTS RELATED TO AD. ELEV 20 ( 1 hPa)


ATIS MACAO: 126.4 APP : ZHUHAI Approach 120.35 / 123.85 (1) HONG KONG Radar 126.3 / 119.1(2) TWR : MACAO Tower 118.0

27 JAN 2022

#### AD 2 - VMMC - 70 VOR/DME RWY 34

PROTECTED FOR A B C D CAT MACAO Ground 121.725 / 121.975

MAX APCH TURNING SPEED : 190 kt IAS MAX MISSED APCH TURNING SPEED : 185 kt IAS



## LEFT

#### APPROACH CHART - ICAO TWR : MACAO Tower 118.0 MCS 111.7 MACAO Ground 121.725 / 121.975 PROTECTED MAX APCH TURNING SPEED : 190 kt IAS 23 FEB 2023 MAX MISSED APCH TURNING SPEED : 185 kt IAS FOR A B C D CAT NANLANG IAF 117.7 NLG $\left( \cdot \right)$ (2100M) CH 124X N22 31.9 E113 33 D11.0 ZUH (900m) VAR 3°W (2016) 22 20 N/S **D9.0 MCS** 2500 JUZHOU ANSHENGWE 117.2 ZAO 116.7 ZUH CH 119X K۰ CH 114X N22 14.7 E113 36.7 FAF MAPT -D2.6 MCS V22 13.3 E113 28.0 D6.0 MCS IAF (1800m) IAS 185 kt 22° PAPI 3° 10' MACAO 116.4 MCU 111.7 MCS CH 111X N22 08 08 E113 35 52 CH 54X 150 N22 09 40 E113 32 54 912 INDUS (1800m) <sup>∞</sup> 4100ft ↓ (1250m) 3000ft (900m) D15.0 ZUH Scale 1/370 000 D7.4 MCU ARP 22° 0 1 2 3 4 5 6 7 8 9 10 km PL I MAM 00 2700ft (800m) 5 NM 0 2 3 4 BEARINGS, TRACKS AND RADIALS ARE MAGNETIC ALTITUDES AND ELEVATIONS ARE IN FEET AND (METERS/m). A 1260 DISTANCES IN NAUTICAL MILES MSA 25NM 113°, 20' 113° 40' 113° <sub>1</sub>30' 113° 50' TA: 9000 (2700 m) **MISSED APPROACH (1)** (MNM climb gradient 3.3% required until D7.4 MCU). Climb on MCU R344° to 4000 ft (1200 m). At MCU FAF MCU 2500 (2480) MAPT(3) 218° <u>1800</u> 1780) VOR track outbound on R171° to DME 7.4 and expect 4000 3980) radar vectoring from Hong Kong Radar to cross 171 INDUS at 1800 m to establish on ZUH R148° and /<u>17</u> /(697) 218 cross ZUH VOR at 1800 m or as directed by ATC. 5.24% When required, join the holding pattern at MCU R171°/DME 7.4 (ZUH R148°/DME 15.0) or proceed as directed by ATC. 9<u>.0 NM</u> →LOC/DME ( NM ) 6 2.6 Standard MNM : vertical distances in feet, horizontal visibility in meters. REF HEIGHT : ALT AD. LOC (3) The approach final segment is offset from landing direction by CIRCLING LOC/DME MCS OCH: 700 054° CAJ On the approach final segment, and at pilot discretion, a visual left NM 6 5 4 3 MDH MDH ΗV ΗV turn should be initiated in time to allow lining up with the runway, 3600 1800 1482 845 A 700 ALT 1163 considering the aircraft type, approach speed before the MAPT. Not Applicable В 700 3600 (825) At MAPT (2.6 NM LOC/DME), even visual, the missed approach (HEIGHT) (1780) (1462) (1143) С 700 3600 procedure is mandatory. D 700 3600 70 kt 85 kt 100 kt 115 kt 130 kt 160 kt 185 kt FAF - MAPT 3.4 NM 2 min 24 2 min 03 2 min 55 1 min 47 1 min 34 1 min 17 1 min 06

ATIS MACAO: 126.4 APP : ZHUHAI Approach 120.35 / 123.85 (1) HONG KONG Radar 126.3 / 119.1(2)


HEIGHTS RELATED TO AD. ELEV 20 ( 1 hPa)

**INSTRUMENT** 

### AD 2 - VMMC - 71 LOC/DME z RWY 16 LOC

**CIVIL AVIATION AUTHORITY- MACAO, CHINA** 

## LEFT



**CIVIL AVIATION AUTHORITY- MACAO, CHINA** 

**UPDATE: Rename LLZ to LOC** 

AIRAC AMDT 02/22

## LEFT

AP	STRUMENT PROACH IART - ICAO	HEIGHTS RELATED AD. ELEV 20 ( 1 hPa	) APP:	HONG KO MACAO T	26.4 pproach 120.35 DNG Radar 126.3 Tower 118.0 Ground 121.725	3 / 119.1(2)	RNP	y RWY 16 (	MMC - 71 B LNAV only)
	OTECTED R A B C D CAT	г		27	JAN 2022	N	MAX APCH T IAX MISSED APCH T	URNING SPEE	
		1739 1749 116.7 ZUH CH 114X N22 13.3 E113 28.0 1AF (1800 m) 12 12 12 12 12 13 12 12 14 15 15 15 15 15 15 15 15 15 15	<sup>1</sup> 5 NM ALS ARE MAGNETIC N FEET AND (METER	117. CH N22 31 MC512 900m) S N N M 4 39 (1089) *28° MC51	UIUZHOU 117.2 ZAO CH 119X 2214.7 E113 36.7 A C508 A APT 10, 00A 20 20 40 40 40 40 40 40 40 40 40 4	6 116.4 MCU CH 111X N22 08 08 E113 3 MC513	o ying to the aer		← 271 °
+			113° (	80'		113° 40	)'  IF	11: TA 9000 (	<sup>3°</sup> i <sup>50'</sup> (2700m)
( T tt V T V V	Turn left and climb on trans hen MC513. Initial clir rectoring from Hong Kong Track to MC514 and ZUH	% required until passing 5. ack 164M to RW16,track mb to 4000ft and expe g Radar to cross INDUS a t at 1800m or as directed b he holding pattern at M as directed by ATC.	to MCU, ct radar t 1800m. oy ATC. C513 at	97 (99		FAF MC509 (1780) 2 <sup>\%</sup>	MC510	500 (480)	(2
	IAPT - (NM)		-3.1		0	2.6	5.6NM		
ΑT	Andard MNM:vertical dist           LNAV           MDA/MDH         HV           970/950         5000           970/950         5000           970/950         5000           970/950         5000           970/950         5000           970/950         5000	ances in feet,horizontal vi CIRCLING MDA/MDH HV Not Applicable	sibility in meters. MAPT(MC508) NM ALT (HEIGHT)	2 1602 (1582)	1 1283 (1263)		1 On the approac discretion, a visual left to allow lining up wit aircraft type, approac MAPT(MC508),even procedure is mandator	turn should be in h the runway, c h speed before visual, the mise	nitiated in time onsidering the the MAPT. At
	FAF-MAPT 2.6NM	70kt 2 min 14	85kt 1 min 50	100kt 1 min 34	115kt 1 min 21	130kt 1 min 12	145kt 1 min 05	160kt 0 min 59	185kt 0 min 51

#### CIVIL AVIATION AUTHORITY- MACAO, CHINA

UPDATE : Annotation of altitude.

AIRAC AMDT 01/21

Sequence	Path		FAF	Fly-	Track °M	Distance	Turn	Altitude	Speed	VPA/	Navigation
Number	Terminator	Waypoint	MAP	over	(°T)	(NM)	Dir	(ft)	(knot)	TCH	Specification
001	IF	MC510						<i>(a)</i> 2500	-190	_	RNP APCH
002	TF	MC509	F		218(215)	3.0		1800	-190	3.00	RNP APCH
003	TF	MC508	М	Y	218(215)	2.524		+1000	-185	3.00	RNP APCH
004	CF	RW16			164(160)	3.16			-185		RNP APCH
005	TF	MCU		—	162(159)	1.61			-185		RNP APCH
006	TF	MC513	—		171(168)	7.1			-185		RNP APCH
007	HM	MC513		Y	328(325)		L	+3000	-185		RNP APCH
008	TF	INDUS	-	-	328(325)	-	-	@5900	-	-	RNP APCH
009	TF	MC514	-	-	328(325)	-	-	@5900	-	-	RNP APCH
010	TF	ZUH	-	-	328(325)	-	-	@5900	-	-	RNP APCH
001	IF	ZUH				_		@5900			RNP APCH
002	TF	MC512			036(033)	10.0		+3000	-190		RNP APCH
003	TF	MC511			093(090)	3.0			-190		RNP APCH
004	TF	MC510			167(164)	5.0		@2500	-190		RNP APCH
001	IF	NLG						@6900			RNP APCH
002	TF	MC511			167(164)	10.4					RNP APCH
003	TF	MC510			167(164)	5.0		@2500	-190		RNP APCH

### FMC Database Coding Reference for RNP y RWY16 APCH

#### Waypoint Coordinates

Waypoint Name		dinates 3884)
INDUS	22°02′41.0″N	113°36′01.0″E
MC508	22°12′25.79″N	113°34′59.76″E
MC509	22°14′34.78″N	113°36′37.67″E
MC510	22°17′02.13″N	113°38′29.61″E
MC511	22°21′49.23″N	113°36′58.39″E
MC512	22°21′49.25″N	113°33′45.41″E
MC513	22°01′09.95″N	113°37′20.04″E
MC514	22°06′52.19″N	113°32′56.82″E
MCU	22°08′08″N	113°35′52″Е
NLG	22°31.9′N	113°33.7′E
RW16	22°09′38.31″N	113°35′14.14″E
ZUH	22°13.3′N	113°28.0′E

#### INSTRUMENT APPROACH CHART - ICAO

HEIGHTS RELATED TO AD. ELEV 20 ( 1 hPa)


ATIS MACAO: 126.4 APP : ZHUHAI Approach 120,35 / 123,85 (1) HONG KONG Radar 126.3 / 119.1(2) TWR : MACAO Tower 118.0 MACAO Ground 121.725 / 121.975

#### AD 2 - VMMC - 71 D LOC/DME x RWY 16 RNAV(GNSS)

PROTECTED FOR A B C D CAT

23 FEB 2023

MAX APCH TURNING SPEED : 190 kt IAS MAX MISSED APCH TURNING SPEED : 185 kt IAS




**CIVIL AVIATION AUTHORITY- MACAO, CHINA** 

### FMC Database Coding Reference for LOC/DME x RWY 16 APCH

Sequence	Path	Waymaint	FAF	Fly-	Track M	Distance	Turn	Altitude	Speed	VPA/	Navigation
Number	Terminator	Waypoint	MAP	over	( °T)	(NM)	Dir	(ft)	(knot)	TCH	Specification
001	IF	ZUH	—			—		@5900	_		RNP APCH
002	TF	MC512	—		036(033)	10.0		+3000	-190		RNP APCH
003	TF	MC511	—		093(090)	3.0		_	-190		RNP APCH
004	TF	MC510	—		167(164)	5.0		@2500	-190		RNP APCH
001	IF	NLG	—			—		@6900			RNP APCH
002	TF	MC511	—		167(164)	10.4	_				RNP APCH
003	TF	MC510	—		167(164)	5.0		@2500	-190		RNP APCH

#### Waypoint Coordinates

Waypoint Name		dinates GS84)
INDUS	22°02′41.0″N	113°36′01.0″E
MC510	22°17′02.13″N	113°38′29.61″E
MC511	22°21′49.23″N	113°36′58.39″E
MC512	22°21′49.25″N	113°33′45.41″E
MCU	22°08′08″N	113°35′52″Е
NLG	22°31.9′N	113°33.7′E
ZUH	22°13.3′N	113°28.0′E




		1	1			1			1		
Seq.	Path	Waypoint	Fix	Fly-	Track °M	Distance	Turn	Altitude	Speed	VPA/	Navigation
Nr.	Terminator		Role	over	(°T)	(NM)	Dir	(ft)	(knot)	TCH	Specification
001	IF	NLG	IAF					@6900	-250		RNP AR APCH
002	TF	MC511			166(163)	10.492		+3000	-190		RNP AR APCH
003	TF	MC800			167(164)	2.500					RNP AR APCH
004	TF	MC802		_	167(164)	1.968	_	_			RNP AR APCH
005	RF Centre: MCC80 r = 2.360NM	MC806			236(233)	2.842	R				RNP AR APCH
006	TF	MC808			236(233)	1.252		@1800	-165	—	RNP AR APCH
001	IF	ZUH	IAF					@5900	-250		RNP AR APCH
002	TF	MC512		_	035(032)	10.030			-190		RNP AR APCH
003	TF	MC511			093(090)	2.981		+3000			RNP AR APCH
004	TF	MC800	—		167(164)	2.500	_	_		_	RNP AR APCH
005	TF	MC802	—		167(164)	1.968	_	_		_	RNP AR APCH
006	RF Centre: MCC80 r = 2.360NM	MC806	_	_	236(233)	2.842	R	_	_	_	RNP AR APCH
007	TF	MC808			236(233)	1.252		@1800	-165		RNP AR APCH
001	IF	MC808	FAF					@1800	-165		RNP AR APCH
002	TF	MC810		_	236(233)	1.435				3.00	RNP AR APCH
003	RF Centre: MCC82 r = 1.600NM	MC812	_	_	164(161)	2.000	L		_	3.00	RNP AR APCH
004	TF	RW16	MAPT	Y	164(161)	2.000		+70		3.00	RNP AR APCH
005	TF	MC820			164(161)	2.559					RNP AR APCH
006	TF	MC822		_	164(161)	2.587					RNP AR APCH
007	RF Centre: MCC84 r = 7.179NM	MC513	_		193(190)	3.624	R	_	-185		RNP AR APCH
008	HM	MC513		Y	328(325)		L	+3000	-185		RNP AR APCH

### FMC Database Coding Reference for RNP z RWY 16 (AR) APCH

#### Waypoint Coordinates

Waypoint Name	Coordinates	(WGS84)	Waypoint Name	Coordinates	(WGS84)
NLG	22°31'54.0000"N	113°33'42.0000"E	MC808	22°14'12.4680"N	113°36'21.1390"E
ZUH	22°13'18.0000"N	113°28'00.0000"E	MC810	22°13'20.0870"N	113°35'07.3230"E
RW16	22°09'38.3100"N	113°35'14.1400"E	MC812	22°11'32.2130"N	113°34'32.1820"E
MC511	22°21'49.2300"N	113°36'58.3900"E	MC820	22°07'12.5500"N	113°36'07.8040"E
MC512	22°21'49.2500"N	113°33'45.4100"E	MC822	22°04'45.1840"N	113°37'02.0200"E
MC513	22°01'09.9500"N	113°37'20.0400"E			
MC800	22°19'24.7490"N	113°37'43.8130"E	MCC80	22°16'51.1470"N	113°35'53.0160"E
MC802	22°17'31.0330"N	113°38'19.5450"E	MCC82	22°12'03.4710"N	113°36'10.0330"E
MC806	22°14'58.1330"N	113°37'25.5250"E	MCC84	22°02'24.8370"N	113°29'43.4130"E



**CIVIL AVIATION AUTHORITY - MACAO, CHINA** 

CORRECTIONS : MAG VAR.

## LEFT




Public Air Traffic

Bearings are magnetic Altitudes and Elevations in Feet AD ELEV : 20 ( 1hPa )



LAT:22° 08' 58" N LONG:113° 35' 29" E

ATIS MACAU : 126.4 TWR MACAU : 118.0




**CIVIL AVIATION AUTHORITY - MACAO, CHINA** 

CORRECTIONS : MAG VAR.

AIRAC AMDT 02/17

## LEFT





## LEFT

### **AD 3. HELIPORTS**

#### AD 3.1 HELIPORT LOCATION INDICATOR AND NAME

### MACAU Heliport

#### AD 3.2 HELIPORT GEOGRAPHICAL AND ADMINISTRATIVE DATA

1	Heliport reference point coordinates and site at heliport	22°11.80'N 113°33.55'E midpoint of the North helipad
2	Direction and distance from city	Eastern edge of Macau.
3	Elevation/Reference temperature	84 ft AMSL / 31.5° C
4	MAG VAR/Annual change	3°W (2016) / -
5	Heliport Administration, address, telephone, telefax, telex, AFS	Heliport Manager Macau Maritime Terminal Av. de Amizade, MACAU Tel : (853) 8893 5803 Telefax : (853) 8893 5801
6	Types of traffic permitted (IFR / VFR)	VFR / SVFR
7	Remarks	Heliport located on the top of the Macau Ferry Terminal.

### AD 3.3 OPERATIONAL HOURS

1	Heliport Dispatch	08:00 to 23:30 local time	
2	Customs and immigration	H24	
3	Health and sanitation	NIL.	
4	AIS Briefing Office	As Heliport Dispatch	
5	ATS Reporting Office	As Heliport Dispatch	
6	MET Briefing Office	As Heliport Dispatch	
7	ATS	As Heliport Dispatch	
8	Fuelling	As Heliport Dispatch	
9	Handling	As Heliport Dispatch	
10	Security	H24	
11	De-icing	NIL.	
12	Remarks	Self-briefing using Aviation Meteorological Information Dissemination System and telephone consultation with MIA	

### AD 3.4 HANDLING SERVICES AND FACILITIES

1	Cargo handling facilities	NIL.	
2	Fuel / oil types	Fuel types : AVTUR JET A1 Oil types : NIL.	
3	Fuelling facilities / capacity	20,000 Litres Jet A-1 total inc. 1,500 litre transfer tank	
4	De-icing facilities	NIL.	
5	Hangar space for visiting helicopter	As Heliport Dispatch	
6	Repair facilities for visiting helicopter	As Heliport Dispatch	
7	Remarks	NIL.	

1	Hotels	In the City.	
2	Restaurants	Within Macau Ferry Terminal and nearby in city.	
3	Transportation	Courtesy Hotel buses, Public buses and taxis, plus ferries	
4	Medical facilities	Nearby City Hospitals.	
5	Bank and Post Office	Bank: Automatic Teller Machines in Macau Ferry Terminal. Post Office: In the city	
6	Tourist Office	Within Macau Ferry Terminal	
7	Remarks	NIL.	

### AD 3.6 PASSENGER FACILITIES

### AD 3.6 RESCUE AND FIRE FIGHTING SERVICES

1	Heliport category for fire fighting	H2
2	Rescue equipment	Light facilities stored adjacent to the helideck
3	Capability for removal of disabled helicopter	FOCC will coordinate and arrange with Technical Engineer for services.
4	Remarks	Category H2 allows aircraft up to and including the size of Aerospatiale AS - 332L to use the Heliport on a regular basis

### AD 3.7 SEASONAL AVAILABILITY - CLEARING

1	Types of clearing equipment	NIL.
2	Clearance priorities	NIL.
3	Remarks	NIL.

1

AD 3.8 APRONS, TAXIWAYS	AND CHECH	<b>K LOCATION DATA</b>	
The stands surface	Surface : Strength :	synthetic surface 9 tones	

	and strength	Strength : 9 tones		
2	Ground taxiway width, surface and Strength	Width :55 m x 15 mSurface :synthetic surfaceDesignation:NIL.		
3	Air taxiway width and Strength	As ground taxiway		
3	ACL location and elevation	NIL.		
4	VOR/INS checkpoints	VOR: NIL. INS: NIL.		
5	Remarks	NIL.		

### AD 3.9 MARKINGS AND MARKERS

1	Final approach and take-off markings	Edge of helipad, marked with a perimeter white line 300mm wide enclosing 'H'
2	TWY, air TWY, air transit route markers	TWY centreline, TWY edge
3	Remarks	NIL.

### AD 3.10 HELIPORT OBSTACLES

In approach/TKOF areas			At heliport		Remarks
1A			1B		
Area affected Obstacle type Coordinates Elevation Markings/LGT		Obstacle type Elevation Markings/LGT	Coordinates		
а	b	с	а	b	
03R/TKOF 21L/APCH			Decoration masts 8 m / 25 ft LGTD	22°11.8'N 113°33.55'E	NIL

1	Associated MET Office	Macau	
1	Associated MET Office	Macau	
2	Hours of service MET office outside hours	H24	
3	Office responsible for TAF preparation Periods of validity	Macau	
4	Type of landing forecasts Interval of issuance	TREND	
5	Briefing/consultation provided	NIL.	
6	Flight documentation Language used	Charts English	
7	Charts and other information available for briefing or consultation	NIL.	
8	Supplementary equipment available for providing information	Current temperature, wind direction and speed can be obtained from the meteorological equipment installed at the Macau Heliport .	
9	ATS units provided with information	Macau TWR	
10	Additional information (limitations of service etc.)	NIL.	

### AD 3.11 METEOROLOGICAL INFORMATION PROVIDED

1	heliport type	Elevated	
2	TLOF dimensions	Northern Helipad –17m x 17m Southern Helipad – 17m x 17m	
3	FATO, GEO and MAG bearings	028° / 208° GEO 031° / 211° MAG	
4	FATO dimensions and SFC type	Northern Helipad – 17m x 17m Synthetic Southern Helipad – 17m x 17m Synthetic	
5	TLOF, SFC and BRG strength	synthetic, 9000 kg	
6	Coordinates of geometric centre TLOF or THR of FATO	N22°11.80 E113°33.55 Midpoint of Northern Helipad N22°11.80 E113°33.60 Midpoint of Southern Helipad	
7	TLOF / FATO, elevation and	elevation : 84 ft (25 m) MSL, slope : 0°	
8	Safety area dimensions	34m x 34m. A 1.5m safety net extends outward from the edges of the helipad.	

### AD 3.12 HELIPORT DATA

### AD 3.13 DECLARED DISTANCES

	TODAH (m)	RTODAH (m)	LDAH (m)	Remarks
	1	2	3	4
FATO 03L		To be notified		
FATO 03R		To be notified		
FATO 21L		To be notified		
FATO 21R		To be notified		

1	APP LGT system type, LEN, INTST	NIL.	
2	Type of visual approach slope indicator system	NIL.	
3	FATO area LGT characteristics and location	White omnidirectional lights	
4	Aiming point LGT characteristics and location	Yellow omnidirectional lights on "H"	
5	TLOF LGT system characteristics and location	White flood light	
6	Remarks	NIL	

### AD 3.14 APPROACH AND FATO LIGHTING

### AD 3.15 OTHER LIGHTING, SECONDARY POWER SUPPLY

1	Heliport BCN location and characteristics Hours of operation	South Eastern corner of Northern Helipad. Hours of operation: 08:00 to 23:00 local time	
2	WDI location and LGT	South Eastern corner of Northern Helipad.	
3	TWY edge and centre line lighting	Centre light	
4	Secondary power supply/switch over time	Available / 2 secs	
5	Remarks	NIL.	

### AD 3.16 ATS AIRSPACE

### NIL.

Service designation	Call sign	Frequency	Hours of operation	Remarks
1	2	3	4	5
TWR	MACAU TWR	118.000 MHz 121.500 MHz	H24	Emergency
FOCC	MACAU HELIPORT	123.500 MHz	0800 – 2330 LT	Company radio

### AD 3.17 ATS COMMUNICATION FACILITIES

### AD 3.18 RADIO NAVIGATION AND LANDING AIDS

#### NIL.

#### **AD 3.19 LOCAL TRAFFIC REGULATIONS**

- **1.** Airline operators shall obtain prior approval from AACM for each specific type of helicopter to be operated.
- 2. Single-engine helicopters are not permitted to operate from the helipad and all operators are required to comply with Category 'A' vertical takeoff and landing profile requirements with zero drop-down.
- **3.** Helicopters are limited to overall length of 18.7m with rotor diameter of 15.6m and a maximum all up weight not exceeding 9,000kg.
- 4. The MH shall be closed and all operations will be ceased when typhoon signal No.8 is hoisted or if the wind condition prevents safe flight operations as determined by the SHM or as prescribed in the Flight Operations Manual of the aircraft operator.
- 5. Tie-down parking outside operating hours will be permitted only when approved by the SHM, provided that during such tie-down period, the premises must be suitably manned. Tie-down of the aircraft is the responsibility of the airline operator or its agent.

#### AD 3.20 NOISE ABATEMENT PROCEDURES

#### To be developed

#### **AD 3.21 FLIGHT PROCEDURES**

- **1.** Traffic circuit
- 1.1. Depending on the wind direction, the helicopter can make a final approach to the pad on tracks 211 or 031°. Departures will be on tracks 031 or 211 or 121° (southern pad only).
- **2.** Landing on 21L/R Helipad
- 2.1. The helicopter shall descend on track 211° and land on the helipad.
- 2.2. If it is unable to make a safe landing, the helicopter shall turn left and climb on track 171° to an altitude of 500 ft. It will then turn left to the downwind track 031° and repeat the approach procedure, following a (standard) left-hand traffic pattern.
- 2.3. Circuit is left-hand for 21L/R landings.
- **3.** Landing on O3L/R Helipad
- 3.1. The helicopter shall descend on track 031° and land on the helipad.
- 3.2. If it is unable to make a safe landing, the helicopter shall turn right and climb on heading 061° to an altitude of 500 ft. It will then turn right to the downwind track 211° and repeat the approach procedure, following a (non-standard) right-hand traffic pattern.
- 3.3. Circuit is right-hand for 03L/R landings.

*Note:* Takeoff 121° heading or Landing 301° heading is permitted at the southern platform only.

If it is unable to make a safe landing on 301°, the helicopter shall turn left and climb to 500' and to a reciprocal heading of 121° until able to re-establish final approach with left turn to final on 301° approach heading.

#### AD 3.22 ADDITIONAL INFORMATION

NIL.

## LEFT